

Instrument						Function		Rem. p.78
Module	Query Param.	Response						
12	Q02	D	1	5	fc +	0 M2=UNUSED 10 M2=AI4-mV 15 M2=AI2-mAmA i 16 M2=AI2-mAmV i 17 M2=AI2-mVmA i 18 M2=AI2-mVmV i 20 M2=AI4 mA p 24 M2=AI4-f/t 25 M2=AI4 mA_MUS 30 M2=AI4-Pt-2W 35 M2=AI2-Pt-3/4 40 M2=AO3-V 50 M2=AO3-mA 60 M2=BIO6-BIN. 2 M2=RS-485 4 M2=PROFIBUS	Slot 2 <u>free</u> 4 x thermocouple/ mV 2 x mA with electrical isolation 1 x mA + 1 x thermocouple with isolation 1 x thermocouple + 1 x mA with isolation 2 x thermocouple with isolation 4 x mA with potential isolation Frequency or time measurement 4 x mA with transmitter supply 4 x Pt100 2-wire circuit 2 x Pt100 3/4-wire circuit Output 3 x V Output 3 x 20 mA 6-fold binary input/output Serial port PROFIBUS module	
	Q03	D	1	5	fc +	0 M3=UNUSED 10 M3=AI4-mV 15 M3=AI2-mAmA i 16 M3=AI2-mAmV i 17 M3=AI2-mVmA i 18 M3=AI2-mVmV i 20 M3=AI4 mA p 24 M3=AI4-f/t 25 M3=AI4 mA_MUS 30 M3=AI4-Pt-2W 35 M3=AI2-Pt-3/4 40 M3=AO3-V 50 M3=AO3-mA 60 M3=BIO6-BIN. 4 M3=PROFIBUS	Slot 3 <u>free</u> 4 x thermocouple/ mV 2 x mA with electrical isolation 1 x mA + 1 x thermocouple with isolation 1 x thermocouple + 1 x mA with isolation 2 x thermocouple with isolation 4 x mA with potential isolation Frequency or time measurement 4 x mA with transmitter supply 4 x Pt100 2-wire circuit 2 x Pt100 3/4-wire circuit Output 3 x V Output 3 x 20 mA 6-fold binary input/output PROFIBUS module	
	Q04	D	1	5	fc +	0 M4=UNUSED 10 M4=AI4-mV 15 M4=AI2-mAmA i 16 M4=AI2-mAmV i 17 M4=AI2-mVmA i 18 M4=AI2-mVmV i 20 M4=AI4 mA p 24 M4=AI4-f/t 25 M4=AI4 mA_MUS 30 M4=AI4-Pt-2W 35 M4=AI2-Pt-3/4 40 M4=AO3-V 50 M4=AO3-mA 60 M4=BIO6-BIN. 2 M4=RS-485 4 M4=PROFIBUS	Slot 4 <u>free</u> 4 x thermocouple/ mV 2 x mA with electrical isolation 1 x mA + 1 x thermocouple with isolation 1 x thermocouple + 1 x mA with isolation 2 x thermocouple with isolation 4 x mA with potential isolation Frequency or time measurement 4 x mA with transmitter supply 4 x Pt100 2-wire circuit 2 x Pt100 3/4-wire circuit Output 3 x V Output 3 x 20 mA 6-fold binary input/output Serial port PROFIBUS module	
Q05	for Protronic 500/550 like slot 3					like slot 3		2

Instrument						Function	Rem. p.78	
Module	Query Param.	Response						
12	Q06	D	1	5	fC	Slot 6 <u>free</u> 4 x thermocouple/ mV 2 x mA with electrical isolation 1 x mA + 1 x thermocouple with isolation 1 x thermocouple + 1 x mA with isolation 2 x thermocouple with isolation 4 x mA with potential isolation Frequency or time measurement 4 x mA with transmitter supply 4 x Pt100 2-wire circuit 2 x Pt100 3/4-wire circuit Output 3 x V Output 3 x 20 mA 6-fold binary input/output Output 4 x relay PROFIBUS module	2	
	Q07					like slot 6	like slot 6	2
20								
PASSWORD								
	Q01	D	1	5	fC	0 <u>PASSWORD OFF</u> 1 <u>PASSWORD_ON</u> 2 <u>PASSWORD_TIME</u>	Password protection is switched off, not activated, but available Password protection is activated Password protection is activated, but stays off for about 30 s after returning to the operating level.	
	P02	D	1	5	fC	PASSWORD	Password definition	
30								
COMMUNICATION								
	P01	D	1	5	fC	ADDRESS 1...127	Unit address on bus 00 = Global address 1 = <u>Factory setting</u>	
	Q02	D	1	5	fC	1 300 BAUD 2 600 BAUD 3 1200 BAUD 4 2400 BAUD 5 4800 BAUD 6 9600 BAUD 7 19200 BAUD 8 38400 BAUD 9 57600 BAUD 10 115200 BAUD 11 187500 BAUD	Baud rate 300 600 1200 2400 4800 9600 19200 38400 57600 115200 187500 only for lateral communication Protronic 500 / 550, Digitric 500	
	Q03	D	1	5	fC	2 <u>MODBUS RTU</u>	Protocol <u>Modbus RTU</u>	
	Q04	D	1	5	fC	0 NONE 2 <u>EVEN</u>	Parity no parity test <u>even</u>	
	Q05	D	1	5	fC	0 NO TIMEOUT 1 <u>SECOND</u> 25 SECONDS	Time out, time monitoring of miss. telegr. on bus without monitoring 1 s 25 s	
	Q06	D	1	5	fC	DP-SLAVE-ADDR 1...125	PROFIBUS device address 1 = <u>Factory setting</u>	



AI Definition			Function	Rem. p.81		
Module	Query Param.					
01	Q02	fc	1 <u>AI01-LINEAR</u> 2 AI01-SQR1 3 AI01-SQR2 4 AI01-TYPE L 5 AI01-TYPE J 6 AI01-TYPE K 7 AI01-TYPE U 8 AI01-TYPE R 9 AI01-TYPE S 10 AI01-TYPE T 11 AI01-TYPE B 12 AI01-TYPE D 13 AI01-TYPE E 14 AI01-RTD-200 15 AI01-RTD-450 16 AI01-RTD-800 17 AI01-TAB1 18 AI01-TAB2 19 AI01-TAB3 20 AI01-TAB4	Linearization <u>linear</u> Square rooting (switch-off < PV0) Square rooting (linear under PV0) Type L (-200...1000 °C) Type J (-200...1200 °C) Type K (-200...1400 °C) Type U (-200... 600 °C) Type R (0...1700 °C) Type S (0...1800 °C) Type T (-200... 400 °C) Type B (0...1800 °C) Type D (0...2300 °C) Type E (-200...1000 °C) Pt 100 -200 ... 200 °C Pt 100 0 ... 450 °C Pt 100 -200 ... 800 °C Table 1 Table 2 Table 3 Table 4	2	
		Q03	fc +	0 <u>AI01 DIM NONE</u> 1 AI01 DIM USER 2 AI01 DIM % 3 AI01 DIM °C 4 AI01 DIM °F 5 AI01 DIM mbar 6 AI01 DIM bar 7 AI01 DIM m3/h 8 AI01 DIM kg/h 9 AI01 DIM t/h 10 AI01 DIM l/h 11 AI01 DIM hl/h 12 AI01 DIM pH 13 AI01 DIM mm 14 AI01 DIM m 15 AI01 DIM m/h 16 AI01 DIM mV 17 AI01 DIM V 18 AI01 DIM mA 19 AI01 DIM A		Dimension for AI01 <u>none</u> 4-digit user-defined  °C °F automatic range switch-over
	to ..	P04	fc +	AI01-USER-DIM - - - -	Edit dimension in the display, if Q03 = 1	
		P05	fc +	AI01-SCAL.LO  Value	Start of scaling (for sensor automatically in °C) Range: -9999 to 99999 Resolution : 1 <u>Factory setting 0 % of measuring range (0.00000)</u>	4
		P06	fc +	AI01-SCAL.HI  Value	End of scaling (for sensor automatically in °C) Range: -9999 to 99999 Resolution : 1 <u>Factory setting 100 % of measuring range (100.00)</u>	4

AI Definition			Function	Rem. p.81
Module	Query Param.			
	Q07	fc 0 AI01 NONE 1 AI01 TREF INT 2 AI01 TREF 0 C 3 AI01 TREF 20C 4 AI01 TREF 50C 5 AI01 TREF 60C	Reference junction compensation no reference junction <u>internal</u> external 0 °C external 20 °C external 50 °C external 60 °C	5
	P08	fc AI01-SQR  Value	Square rooting value of PV0 Range -9999 to +99999, Resolution 0.01 <u>Factory setting 0.0</u>	
	P09	fc AI01-FILTERT.  Value	T-Filter time constant Range 0 to 120 s Resolution 1 s <u>Factory setting 0 s (0.00.00 h)</u>	
	Q10	fc 1 AI01-FAIL.VAL 2 AI01-OLD VAL.	Default value strategy for sensor fault <u>Default value</u> Hold last measured value	
	P11	fc AI01-FAIL.VAL  Value	Default value Range 0 to 102 % Resolution 0.0001 <u>Factory setting 102 %</u>	
	Q12	fc 0 AI01-ERR=N.BO 1 AI01-ERR=BO01   76 AI01-ERR=BO76	Error message via BOx <u>No message</u> BO01   BO76	
	Q13	fc 0 AI01=N.FLG 1 AI01ERR=FLG01 2 AI01ERR=FLG02 3 AI01ERR=FLG03 4 AI01ERR=FLG04 5 AI01ERR=FLG05 6 AI01ERR=FLG06	Error message via Flag <u>No message</u> via Flag 1 via Flag 2 via Flag 3 via Flag 4 via Flag 5 via Flag 6	
	Q15	fc 1 NAMUR + 2 NAMUR - 3 NAMUR +/- 4 24 V POS 5 24 V NEG 6 24 V +/- 7 TTL POS 8 TTL NEG 9 TTL +/-	Pick-up acc. to NAMUR DIN 19 232 positive edge Pick-up acc. to NAMUR DIN 19 232 negative edge Pick-up acc. to NAMUR DIN 19 232 both edges binary signal 0/24 V positive edge binary signal 0/24 V negative edge binary signal 0/24 V both edges TTL signal 0/5 V positive edge TTL signal 0/5 V negative edge TTL signal 0/5 V both edges	6

1 Only for AI01 and module 2\_Pt100\_3/4L.

2 For modules for Pt 100.

3 Text in unit Alxy-Bxy-Fn  
Module number is identical with input number  
x = Module on slot, y = input y on module x

4 Scaling is according to the transmitter data. The scaling for the control variable can deviate from this. See Lx-B03-P07, P08.

5 Reference junction only for thermocouple.

6 Only modules.

7 If only one input per module is used.

8 Two pulse inputs required for measuring.

9 Three pulse inputs required for measuring.

AO Definition			function	Rem. p.81
Module	Query Param.			
01 to ...				
<div>Protronic 100: AO01 Protronic 500/550: AO01 ... AO73 Digitric 500: AO01 ... AO43 (Analog outputs)</div>				
Q01	fc +	0 UNUSED 1 AO01 DEAD ZERO <u>2 AO01 LIFE ZERO</u> 4 AO01 10 mA 5 AO01 20 mA	Signal range output AOxy unused (not for AO01) 0...20 mA <u>4...20 mA</u> 10 mA constant current for current module 20 mA constant current for current module	1 1
Q02	fc	<u>0 AO01 LD=N.BO</u> 1 AO01 LD.=BO01   76 AO01 LD.=BO76	Output of impedance monitoring, Output via <u>No output</u> BO01   BO76	
Q03	fc	<u>0 AO01 LD=N.FLG</u> 1 AO01 LD=FLG01 2 AO01 LD=FLG02 3 AO01 LD=FLG03 4 AO01 LD=FLG04 5 AO01 LD=FLG05 6 AO01 LD=FLG06	Error message via Flag <u>No message</u> via Flag 1 via Flag 2 via Flag 3 via Flag 4 via Flag 5 via Flag 6	

- 1 For output module AO3\_V:  
0...20 mA stands for 0...10 V  
4...20 mA stands for 2...10 V

BIO-Definition			Function	Rem. p.81
Module	Query Param.			
01 to ...				
<div>Protronic 100: BIO01 ... BIO 04 Protronic 500/550: BIO01 ... BIO74 Digitric 500: BIO01 ... BIO46</div>				
Q01	fc +	0 UNUSED 1 BIO1 DIRECT 2 BIO1 INVERS 3 BO01 ENGISED 4 BO01 DENGISED	Unused for modules Binary 1 = input contact = "1" Binary 1 = input contact = "0" Binary 1 = output - operating current Binary 1 = output - quiescent current	1 2

- 1 In Digitric 500, BO03 and BO04 are designed as relay outputs and cannot be configured as inputs.  
Q01 = 0 not for BIO01 to BIO04
- 2 With free configuration, only the following functions can be exchanged subsequently in the list configuration: function 1 for 3 and/or function 2 for 4.

Loop 1					Function		Rem. S.96
Module	Query Param.	Response					
01 CONTROLLER FUNCTION							
Q01	D	1	5	fc +	1 SINGLE LOOP 3 SLAVE CONTR. 4 OVERR.M.MIN 5 OVERR.M.MAX 8 MANUALSTATION 9 SETPT.STATION 10 RATIO STATION 11 POSITIONER	Single-channel controller Slave controller in cascade Min. override adjustment Master controller Max. override adjustment Master controller Single-channel manual station Single-channel set point station Single-channel ratio station Single-channel positioner	
Q02	D	1	5	fc	1 CONTINUOUS 2 STEP CONTR. 3 ON/OFF CONTR. 5 H-OFF-C (S+S) 6 H-OFF-C (C+S) 7 SPLIT.R. (C+C)	Controller output K = continuous S = step Z = two-position D = three position heat-o-cool (relay) D = three-position Heat (cont.)-o-cool (relay) KK = split range with 2 continuous outputs	
Q03	D	1	5	fc	1 M:CHAR-DIR 2 M:CHAR-INV 3 M:INV-DIR 4 M:DIR-DIR 5 M:INV-INV 6 M:DIR-INV	Manual characteristic Position display =   0 %   50 %   100 %   Z=K   off   on     on   off   D   out2on   out2off   out1off   out1on   =   out2off   out2on   out1off   out1on   KK   out2on   out2off   out1on   out1off     out2off   out2on   out1on   out1off   S   independent of wiring  off = permanently off or 0/4 mA; on = permanently on or 20 mA	
Q04	D	1	5	fc +	0 NO PS.FBACK 1 POS.FBCK=AI01 2 POS.FBCK=AI02 44 POS.FBCK=AI44 74 POS.FBCK=AI74	y-feedback signal and display No y-feedback signal AI01 AI02 AI44 AI74	
Q05	D	1	5	fc +	0 SELFTUNE OFF 1 SELFTUNE1 ON	Self-tuning Off On	
02 CONTROLLER PARAMETER							
Q01	D	1	5	fc	1 A:CHAR.-DIR. 2 A:CHAR.-INV.	Aut. characteristic automatic direct action characteristic Automatic indirect action characteristic	
Q02	D	1	5	fc +	1 P CONTROL 2 PI CONTROL 3 PD CONTROL 4 PID CONTROL 5 PI+DEADTIME 6 PID+DEADTIME	PI-behaviour P (I for step controller) PI PD (not with step controller) PID Smith Predictor with PI Smith Predictor with PID	
Q03	D	1	5	fc	1 DIFF. PV 2 DIFF. ERROR	D compartment connected with controlled variable Controller deviation	

[illegible]



Loop 1						Function	Rem. S.96
Module	Query Param.	Response					
	Q29	D	1	5	FC	Disturbance variable adds to Out <u>linear</u> different. bipolar different. unipolar positive changes different. unipolar negative changes	
						1 FF:LINEAR 2 FF:DIF.BIPOL 3 FF:DIF.UNIPOL+ 4 FF:DIF.UNIPOL-	
03 INPUT CIRCUIT							
Q01	D	1	5	FC	0 NO INPUT CIRC 1 ONE PV 2 3 COMPONENT 3 MULTIPLICATE 4 RATIO1 5 FIX/RATIO1 6 RATIO2 7 FIX/RATIO2 8 EXTR.PV.MAX 9 EXTR.PV.MIN 10 EXTR.SP.MAX 11 EXTR.SP.MIN 12 LOAD AIR 13 LOAD FUEL	Input circuit Without input signal connection (stations) <u>Fixed value Err = IC1 - SP</u> Multicomponents Err = IC1 x K1 - SP + K2 x (IC2 + K3 x IC3) Multiplication Err = IC1 x (IC2 + K3 x IC3) - SP ratio1 Err = IC1 - (R x (IC2 + K3 x IC3) + Bias + IC4) Fixed value/ratio1 switchable (1 <-> 4) ratio2 Err = IC1 - [(R / (1 - R)) x (IC2 + K3 x IC3) + Bias + IC4] Fixed value/ratio2 switchable (1 <-> 6) Extreme value PV: Err = Max(IC1,..IC3) - SP Extreme value PV: Err = Min(IC1,..IC3) - SP Extreme value SP: Err = IC1 - Max(SP1,IC2,IC3) Extreme value SP: Err = IC1 - Min(SP1,IC2,IC3) Air control for air (only loop 1) Air control for fuel (only loop 2)	1   

Loop 1						Function	Rem. S.96
Module	Query Param.	Response					
03	Q06	D	1	5	fC	0 P,S 10000. 1 P,S 1000.0 2 P,S 100.00 3 P,S 10.000 4 P,S 1.0000 5 P,S FLOAT.PT. 0 decimal places 1 decimal place 2 decimal places 3 decimal places 4 decimal places Display of floating decimal point	
	P07	D	1	5	fC	DIG.IND.LO. Value Scaling for PV, SP Start Factory setting SP = 0,0 Range -9999 to 99999	3
	P08	D	1	5	fC	DIG.IND.HI Value Scaling for PV, R(SP) End Factory setting SP = 100,0 Range -9999 to 99999	3
	Q09	D	1	5	fC	1 RATIO IS/SP 2 ES1, RATIO × ES2 Digital display for ratio Ract and Rset IC1 and R × IC2	
	Q10	D	1	5	fC	0 NO DIM. 1 USER DIM. 2 DIM. = % Dimension R ratio for ratio and multiplication without dimension (e.g. ratio) 4-digit dimension freely definable % (Factory setting for ratio 2)	
	P11	D	1	5	fC	R USER DIM. - - - - Edit the user dimension ratio (if Q04 = 1) see AI Definition Q04	
	Q12	D	1	5	fC	0 R 10000. 1 R 1000.0 2 R 100.00 3 R 10.000 4 R 1.0000 5 R FLOAT.PT. 0 Decimal places 1 Decimal places 2 Decimal places 3 Decimal places 4 Decimal places Display of floating decimal point	
	P14	D	1	5	fC	SCAL.RATIO Value Scaling for ratio Factory setting R = 100.0 Range -9999 to 99999	
	Q15	D	1	5	fC	1 ANALOG PV,SP 2 ANALOG RATIO Analog display for ratio PV1 and R × PV2 Ract and Rset	8
	P16	D	1	5	fC	ANALOG.0 Value Analog.0% s. B03-Q15 Value of analog display for 0 % Factory setting 0.0 Range -9999 to 99999	9
	P17	D	1	5	fC	ANALOG.100 Value Analog.100% see B03-Q15 Value of analog display for 100 % Factory setting 100.0 Range -9999 to 99999	9
	Q18	D	1	5	fC	0 PV,R=NO AO 1 PV,R=AO01   43 PV,R=AO43   73 PV,R=AO73 PV retransmission Current control variable or Ract to Not routed to output Analog output AO01   Analog output AO43   Analog output AO73	

Loop 1					Function	Rem. S.96
Module	Query Param.	Response				
04						
ROUTING_ES-AI						
Routing of the analog inputs and the input circuit()						
Q01	D	1	5	FC	Routing_IC1 IC1 of input circuit connected with: fixed value 0 % <u>AI01 for loop</u> AI02   AI44   AI74 Output of the state correction 1 Output of the state correction 2 Output of Table 4 Fixed value 100 %	
					0 ES1=0% 1 ES1=AI01 2 ES1=AI02   44 ES1=AI44   74 ES1=AI74 91 ES1=FC_1 92 ES1=FC_2 94 ES1=TAB4 100 ES1=100%	
Q02	D	1	5	FC	Routing_IC2 IC2 of the input circuit connected with: as IC1	
					like Q01	
Q03	D	1	5	FC	Routing_IC3 IC3 of the input circuit connected with: like IC1	
					like Q01	
Q04	D	1	5	FC	Rangier_IC4 IC4 of the input circuit connected with: like IC1	
					like Q01	
Q05	D	1	5	FC	TAB4.AI Table 4 connected with <u>Not individually used</u> AI01 AI02   AI44   AI74	
					0 TAB4 NO.AI 1 TAB4.AI01 2 TAB4.AI02   44 TAB4.AI44   74 TAB4.AI74	
Q06	D	1	5	FC	Routing_B1 Routing of binary signal with B1x <u>B1 unused</u> BI01   BI04   BI46   BI76	
					0 B1 NO BI 1 B1=BI01   4 B1=BI04   46 B1=BI46   76 B1=BI76	
05						
SETPOINTS						
Q01	D	1	5	FC	Setpoint 1 of controller 1 off <u>can only be changed per keys or interface</u> follows current set point	
					0 SP1.INT=OFF 1 SP1.INT=ON 2 SP1.INT=TRACK	
Q02	D	1	5	FC	Type SP1 SP1 as parameter (then becomes part of the configuration and can be taken over by other unit per Conf1) <u>no</u> yes is not tracked	
					0 SP1=NO PARAM. 1 SP1=PARAM.	

Loop 1						Function	Rem. S.96															
Module	Query Param.	Response																				
05	Q03	D ● ● ● ● ●	1 ● ● ● ●	5 ● ● ● ●	fc     	0 <u>SP2.INT=OFF</u> 1 <u>SP2.INT=ON</u> 2 <u>SP2.INT=PARA.FLX</u> 3 <u>SP2=DELTA.PAR</u> 4 <u>SP2=RATIO.TRK</u>	Set point 2 = ratio set point 1 SR1 <u>off</u> Only changeable per key or interface Only operatable at paralevel Delta only operatable at paralevel SR1 follows actual ratio															
	Q04	D ● ● ● ● ●	1 ● ● ● ●	5 ● ● ● ●	fc     	0 <u>SP3.INT=OFF</u> 1 <u>SP3.INT=ON</u> 2 <u>SP3.INT=PARA.FLX</u> 3 <u>SP3=DELTA.PAR</u>	Set point 3 = ratio set point 2 SR2 <u>off</u> Only changeable per key or interface Only operatable at paralevel Delta only operatable at paralevel															
	Q05	D ● ● ● ● ●	1 ● ● ● ●	5 ● ● ● ●	fc     	0 <u>SP4.INT=OFF</u> 1 <u>SP4.INT=ON</u> 2 <u>SP4.INT=PARA.FLX</u> 3 <u>SP4=DELTA.PAR</u>	Set point 4 = ratio set point 3 SR3 <u>off</u> only changeable per keys or interface Only operatable at paralevel Delta only operatable at paralevel															
	Q06	D ● ● ● ● ● - -	1 ● ● ● ● - -	5 ● ● ● ● ● ● ●	fc       	0 <u>SP.EXT=OFF</u> 1 <u>SP.EXT=AI01</u> 2 <u>SP.EXT=AI02</u>   44 <u>SP.EXT=AI44</u>   74 <u>SP.EXT=AI74</u>	External set point <u>off</u> AI01 AI02   AI44   AI74															
	Q07	D ● ● ●	1 ● ● ●	5 ● ● ●	fc   	0 <u>SP.COMP=OFF</u> 1 <u>SP.COMP=ON</u>	Computer set point <u>off</u> on															
	Q08	D ● ● ●	1 ● ● ●	5 ● ● ●	fc   	0 <u>SP.PRGRM=OFF</u> 1 <u>SP.PRGRM=ON</u>	Program transmitter set point <u>off</u> on	4														
	Q09	D  ● ●	1  ● ●	5  ● ●	fc +   	1 <u>SP:IND/TARGET</u> 2 <u>SP.IND.RAMP</u>	SP Display Display of set point falsified temporarily by ramp <u>Display of the targeted set point</u> Display of the falsified value. The targeted set point is displayed during set point adjustment, 3 s after the last actuating key of the current set point.															
	Q10	D ● ● ● ● - - -	1 ● ● ● ● - - -	5 ● ● ● ● ● ● ●	fc       	0 <u>SP.ACT.NO AO</u> 1 <u>SP.ACT=AO01</u>   43 <u>SP.ACT=AO43</u>   73 <u>SP.ACT=AO73</u>	Current set point to AOx <u>Set point not on output</u> Analog output AO01   Analog output AO43   Analog output AO73															
	Q11	D ●  ● ●	1 ●  ● ●	5 ●  ● ●	fc     	0 <u>SP.TRANS=OFF</u>   1 SP1-SP2 Bix  2 SP1-SP4 BIy	SP Changeover Set point changeover <u>off</u> <table><tr><th>Bix</th><th>BIy</th><th>Setpoint</th></tr><tr><td>0</td><td>0</td><td>1</td></tr><tr><td>1</td><td>0</td><td>2</td></tr><tr><td>0</td><td>1</td><td>3</td></tr><tr><td>1</td><td>1</td><td>4</td></tr></table> Definition Bix, BIy see B09-Q13, Q14	Bix	BIy	Setpoint	0	0	1	1	0	2	0	1	3	1	1	4
Bix	BIy	Setpoint																				
0	0	1																				
1	0	2																				
0	1	3																				
1	1	4																				

Loop 1					Function		Rem. S.96
Module	Query Param.	Response					
06 TREND INDICATION							
Q01	D	1	5	fc +	Time for trend display in graphic display of Protronic 550	13	
	-	-	•		1 TREND 75 sec		
	-	-	•		2 TREND 3 min		
	-	-	•		3 TREND 5 min		
	-	-	•		4 TREND 10 min		
	-	-	•		5 TREND 20 min		
	-	-	•		6 TREND 30 min		
	-	-	•		7 TREND 1 h		
	-	-	•		8 TREND 2 hrs		
	-	-	•		9 TREND 3 hrs		
	-	-	•		0 TREND 5 hrs		
07 CONTROLLER MODES							
Q01	D	1	5	fc	Type of operation Manual/Automatic only manual only automatic only automatic, manual adjustment has effect on min. threshold for Out only automatic, manual adjustment has effect on max. threshold for Out manual/automatic/cascade manual/automatic/computer(DDC) manual/computer(DDC)	10 10	
	•	•	•		1 MODE=MAN/AUTO		
	•	•	•		2 MODE=MAN		
	•	•	•		3 MODE=AUT		
	•	•	•		4 MODE=AUTO_MIN		
	•	•	•		5 MODE=AUTO_MAX		
	•	•	•		6 MAN/AUT/CASC		
	•	•	•		7 MAN/AUT/DDC		
	•	•	•		8 MAN/DDC		
Q02	D	1	5	fc	SP-Tracking (SP is set to PV) SP1 tracking for Man OFF SP1 tracking for Man On has effect on SP1 and RAMP SP1 tracking for Man On has effect only on RAMP		
	•	•	•		0 TRACK SP OFF		
	•	•	•		1 TRACK SP/ACT		
	•	•	•		2 TRACK SP		
Q03	D	1	5	fc	DDC function No DDC In case of computer failure: Manual + last correction value Man. + safety correct. value 0 % Manual + saftey correct. value 1 Manual + safety correct. value 2 begins automatically with last correction value cascade		
	•	•	•		0 DDC=OFF		
	•	•	•		1 DDC=MAN,HOLD		
	•	•	•		2 DDC=MAN OUT=0		
	•	•	•		3 DDC=MAN OUTS1		
	•	•	•		4 DDC=MAN OUTS2		
	•	•	•		5 DDC=AUTO		
	•	•	•		6 DDC=CASC		
Q04	D	1	5	fc	SP Back-up Set point in case of computer failure (HOST) Adjusted set point Computer set point last control variable (PV-tracking)		
	•	•	•		0 SP-ACTUAL		
	•	•	•		1 SP-COMP.		
	•	•	•		2 PV-ACTUAL		
Q05	D	1	5	fc	OM Operation Operation mode after mains resumption Previous operation mode Manual last correction value Manual safety correct. value 0 % Manual safety correct. value 1 Manual safety correct. value 2		
	•	•	•		1 POWER=OLDMODE		
	•	•	•		2 POWER=MAN,HLD		
	•	•	•		3 POWER=MAN,0%		
	•	•	•		4 POWER=MAN,S1		
	•	•	•		5 POWER=MAN,S2		
Q06	D	1	5	fc	Operation mode during fault at input (fault on PV) No change Manual, last correction value Man., safety correct. value 0 % Manual, safety correct. value 1 Manual, safety corect. value 2		
	•	•	•		1 ?AI=OLD MODE		
	•	•	•		2 ?AI=MAN,HOLD		
	•	•	•		3 ?AI=MAN,0%		
	•	•	•		4 ?AI=MAN,S1		
	•	•	•		5 ?AI=MAN,S2		

Loop 1					Function		Rem. S.96
Module	Query Param.	Response					
08					ALARMS		
Q01	D	1	5	fc	0 ALARM1=OFF	Alarm value 1	
	•	•	•		1 ALARM1 SP.MIN	Alarm value without function	
	•	•	•		2 ALARM1 SP.MAX	Alarm value to PV - Min	
	•	•	•		3 ALM1 ERR-MIN	Alarm value to PV - Max	
	•	•	•		4 ALM1 ERR-MAX	Alarm value to Err - Min	
	•	•	•		6 ALM1  ERR -MX	Alarm value to Err - Max	
	•	•	•		7 AL1 ER-SP%MIN	Alarm value to  Err  - Max	
	•	•	•		8 AL1 ER-SP%MAX	Alarm value to Err - Min in % of SP	
	•	•	•		10 AL1  ERR S%,MAX	Alarm value to Err - Max in % of SP	
	•	•	•		11 AL1 DX/DT-MAX	Alarm value to  Err  - Max in % of SP	
	•	•	•		12 AL1 RATIO MIN	Alarm value dx/dt Max	
	•	•	•		13 AL1 RATIO MAX	Alarm value R = Min. for input Ratio	
	•	•	•		14 AL1 OUT-MIN	Alarm value R = Max. for input Ratio	
	•	•	•		15 AL1 OUT-MAX	Alarm value to Out - Min	
						Alarm value to Out - Max	
Q02	D	1	5	fc		Alarm value 2	
	•	•	•		2 ALARM2 SP.MAX	like alarm value 1 default alarm value to PV - Max	
Q03	D	1	5	fc		Alarm value 3	
	•	•	•		3 ALM3 ERR-MIN	like alarm value 1 Alarm value to Err - Min	
Q04	D	1	5	fc		Alarm value 4	
	•	•	•		4 ALM4 ERR-MAX	like alarm value 1 Alarm value to Err - Max	
Q05	D	1	5	fc		Type Alarm 1	
	•	•	•		1 ALM1 OP/OP	adjustable to	displayed in
	•	•	•		2 ALM1 PAR/OP	Operation level	Operation level
	•	•	•		3 ALM1 PAR/PAR	Para-Level	Operation level
Q06	D	1	5	fc		Type Alarm 2	
	•	•	•		1 ALM2 OP/OP	adjustable to	displayed in
	•	•	•		2 ALM2 PAR/OP	Operation level	Operation level
	•	•	•		3 ALM2 PAR/PAR	Para-Level	Operation level
Q07	D	1	5	fc		Type Alarm 3	
	•	•	•		1 ALM3 OP/OP	adjustable to	displayed in
	•	•	•		2 ALM3 PAR/OP	Operation level	Operation level
	•	•	•		3 ALM3 PAR/PAR	Para-Level	Operation level
Q08	D	1	5	fc		Type Alarm 4	
	•	•	•		1 ALM4 OP/OP	adjustable to	displayed in
	•	•	•		2 ALM4 PAR/OP	Operation level	Operation level
	•	•	•		3 ALM4 PAR/PAR	Para-Level	Operation level
09					BINARY INPUTS		
Q01	D	1	5	fc	0 MAN.BI OFF	Changeover to Manual with last Out-value	
	•	•	•		1 MAN.BI01	No function	
	•	•	•		4 MAN.BI04	BI01	
	•	•	•		46 MAN.BI46	BI04	
	•	•	•		76 MAN.BI76	BI46	
	•	•	•			BI76	
	•	•	•				
	•	•	•				

Loop 1						Function	Rem. S.96
Module	Query Param.	Response					
09	Q02	D ● ●	1 ● ●	5 ● ●	fc  <u>1 MAN STATIC</u> 2 MAN DYNAMIC	Dyn.<-->Stat. function depends on duration of bin. input (0 = PREVIOUS MODE, 1 = MAN) Changing 0 to 1 switches MAN-AUT-MAN	7
	Q03	D ● ● ● ● ● ● ● ● ● ●	1 ● ● ● ● ● ● ● ● ● ●	5 ● ● ● ● ● ● ● ● ● ●	fc  <u>0 CASC.BI AUS</u> 1 CASC.BI01   4 CASC.BI04   46 CASC.BI46   76 CASC.BI76	Cascade Bix Changeover Autom <--> Cascade <u>like query 1</u>	
	Q04	D ● ●	1 ● ●	5 ● ●	fc  <u>1 CASC STATIC</u> 2 CASC DYNAMIC	Dynamic <--> Static function depends on duration of binary input Changing 0 to 1 switches	
	Q05	D ● ● ● ● ● ● ● ● ● ●	1 ● ● ● ● ● ● ● ● ● ●	5 ● ● ● ● ● ● ● ● ● ●	fc  <u>0 MAN Y=0% BI OFF</u> 1 MAN Y=0% BI01   4 MAN Y=0%.BI04   46 MAN Y=0%.BI46   76 MAN Y=0%.BI76	Changeover to manual mode with Out = 0 % <u>like query 1</u>	7,11
	Q06	D ● ●	1 ● ●	5 ● ●	fc  <u>1 MAN 0%.STATIC</u> 2 MAN 0%.DYNAM	Dynamic <--> Static function depends on duration of the binary input Changing 0 to 1 switches	7,11
	Q07	D ● ● ● ● ● ● ● ● ● ●	1 ● ● ● ● ● ● ● ● ● ●	5 ● ● ● ● ● ● ● ● ● ●	fc  <u>0 MAN YS1 BI OFF</u> 1 MAN YS1.BI01   4 MAN YS1.BI04   46 MAN YS1.BI46   76 MAN YS1.BI76	Changeover to manual mode with safety output value 1 <u>like query 1</u>	11
	Q08	D ● ●	1 ● ●	5 ● ●	fc  <u>1 MAN YS1 STATIC</u> 2 MAN YS1 DYNAM	Dynamic <--> Static function depends on duration of the binary input Changing 0 to 1 switches	7,11
	Q09	D ● ● ● ● ● ● ● ● ● ●	1 ● ● ● ● ● ● ● ● ● ●	5 ● ● ● ● ● ● ● ● ● ●	fc  <u>0 MAN YS2 BI OFF</u> 1 MAN YS2.BI01   4 MAN YS2.BI04   46 MAN YS2.BI46   76 MAN YS2.BI76	Changeover to manual mode with safety output value 1 <u>like query 1</u>	11
	Q10	D ● ●	1 ● ●	5 ● ●	fc  <u>1 MAN YS2 STATIC</u> 2 MAN YS2 02	Dynamic <--> Static function depends on <u>like query 2</u>	7,11
	Q11	D ● ● ● ● ● ● ● ● ● ●	1 ● ● ● ● ● ● ● ● ● ●	5 ● ● ● ● ● ● ● ● ● ●	fc  <u>0 TRCKOUT BI OFF</u> 1 TRCKOUT.BI01   4 TRCKOUT.BI04   46 TRCKOUT.BI46   76 TRCKOUT.BI76	Switch on output tracking (Out = AIxy) like query 1  see Lx-B10-Q10	11

Loop 1						Function	Rem. S.96	
Module	Query Param.	Response						
09	Q12	D	1	5	fc	<u>0 SRAMP BI OFF</u> 1 SRAMP=0.BI01   4 SRAMP=0.BI04   46 SRAMP=0.BI46   76 SRAMP=0.BI76	Ramp stop static SP ramp stopped. like query 1	
	Q13	D	1	5	fc	<u>0 SP1-4 BIX OFF</u> 1 SP1-4 BIX=BI01   4 SP1-4 BIX=BI04   46 SP1-4 BIX=BI46   76 SP1-4 BIX=BI76	SP changeover: Definition of BIX (B05-Q11) <u>No setpoint changeover with BIX</u> with BI01   BI04   BI46   with BI76	
	Q14	D	1	5	fc	<u>0 SP1-4 BIY OFF</u> 1 SP1-4 BIY=BI01   4 SP1-4 BIY=BI04   46 SP1-4 BIY=BI46   76 SP1-4 BIY=BI76	SP changeover: Definition of BIY (B05-Q11) <u>No setpoint changeover with BIY</u> with BI01   BI04   BI46   with BI76	
	Q15	D	1	5	fc	<u>0 SPI-EXT BI OFF</u> 1 SPI-EXT.BI01   4 SPI-EXT.BI04   46 SPI-EXT.BI46   76 SPI-EXT.BI76	SPint <-> SPext static changeover <u>like query 1</u>	
	Q16	D	1	5	fc	<u>0 CHAR BI OFF</u> 1 CHAR BI.BI01   4 CHAR BI.BI04   46 CHAR BI.BI46   76 CHAR BI.BI76	DIR <-> INV static Changeover of characteristic <u>like query 1</u>	
	Q17	D	1	5	fc	<u>0 LOCK SP BI OFF</u> 1 LOCK SP.BI01   4 LOCK SP.BI04   46 LOCK SP.BI46   76 LOCK SP.BI76	Locking SP change static Inhibition of the SP adjustment capability with <u>like query 1</u>	
	Q18	D	1	5	fc	<u>0 REMOTE BI=OFF</u> 1 REMOTE SP 2 REMOTE OUT 3 A=SP,M=OUT	Enabling of teleadjustment (static) <u>Inhibition of teleadjustment</u> only setpoint (in all operation states) only correction value (in manual) setpoint in automatic, Out in manual	



Loop 1						Function	Rem. S.96	
Module	Query Param.	Response						
09	Q19	D	1	5	fc	0 MORE BI OFF 1 MORE.BI01   4 MORE.BI04   46 MORE.BI46   76 MORE.BI76	Teleadjustment (more) 100%/60s- adjustment with BI01   with BI04   with BI46   with BI76	
	Q20	D	1	5	fc	1 LESS BI OFF   4 LESS.BI04   46 LESS.BI46   76 LESS.BI76	Teleadjustment (less) 100%/60s-adjustment with BI01   with BI04   with BI46   with BI76	
	Q21	D	1	5	fc	0 CR BI OFF 1 CR BI01   4 CR BI04   46 CR BI46   76 CR BI76	Computation ready not used via binary input BI01   via binary input BI04   via binary input BI46   via binary input BI76	
10								
ROUTE OUT (Routing of the controller outputs)								
Q01	D	1	5	fc	0 OUT1 NO AO 1 OUT1.CON=AO01   43 OUT1.CON=AO43   73 OUT1.CON=AO73	Routing Out1 to AOx first continuous controller output to for switching controllers Analog output AO01   Analog output AO43   Analog output AO73		
Q02	D	1	5	fc	0 OUT2 NO AO 1 OUT2.CON=AO01   43 OUT2.CON=AO43   73 OUT2.CON=AO73	Routing Out2 to AOx second continuous controller output (split range) Unused Analog output AO01   Analog output AO43   Analog output AO73		
Q03	D	1	5	fc	0 OUTA NO AO 1 OUTA.CON=AO01   43 OUTA.CON=AO43   73 OUTA.CON=AO73	Routing Out to AOx Diagram of position display Out for switching controllers and split range No output Analog output AO01   Analog output AO43   Analog output AO73		
Q04	D	1	5	fc	0 OUT1=NO BO 1 OUT1=BO01   4 OUT1=BO04   46 OUT1=BO46   76 OUT1=BO76	Routing Out1 to BOx First switch contact (for step controller 'more') for continuous controller to binary output BO01   to binary output BO04   to binary output BO46   to binary output BO76		

Loop 1						Function	Rem. S.96	
Module	Query Param.	Response						
10	Q05	D	1	5	fc	0 OUT2=NO BO 1 OUT2=BO01   4 OUT2=BO04   46 OUT2=BO46   76 OUT2=BO76	Routing of Out2 to B0x second switch contact (for step controller 'less') <u>for continuous controller</u> to binary output B001   to binary output B004   to binary output B046   to binary output B076	6
	Q06	D	1	5	fc	0 OUT.LIMIT=OFF 1 OUT.LIMIT.AUT 2 OUT.LIMIT=ON	Output limits <u>always inactive (for step controller)</u> active only in automatic operation active in manual and automatic operation	
	Q08	D	1	5	fc	0 OUT-MAX=PAR 1 OUT-MAX=AI01 2 OUT-MAX=AI02   44 OUT-MAX=AI44   74 OUT-MAX=AI74	Out-Max int./extern. defined <u>Internal parameter</u> routed through AI01 routed through AI02   routed through AI44   routed through AI74	
	Q09	D	1	5	fc	0 OUT-MIN=PARAM. 1 OUT-MIN=AI01 2 OUT-MIN=AI02   44 OUT-MIN=AI44   74 OUT-MIN=AI74	Out-Min int./extern. defined <u>Internal parameter</u> routed through AI01 routed through AI02   routed through AI44   routed through AI74	
	Q10	D	1	5	fc	0 OUT-TRCK=AUS 1 OUT-TRCK=AI01 2 OUT-TRCK=AI02   44 OUT-TRCK=AI44   74 OUT-TRCK=AI74	Out Track (see B09-Q11) <u>No Out tracking</u> Out = AI01 if B1x Out = AI02 if B1x   Out = AI44 if B1x   Out = AI74 if B1x	
11								
BINARY OUTPUTS								
11	Q01	D	1	5	fc	0 ALARM1.NO BO 1 ALARM1.BO01   4 ALARM1.BO04   46 ALARM1.BO46   76 ALARM1.BO76	Alarm value 1 to output <u>No output</u> BO01   BO04   BO46   BO76	
	Q02	D	1	5	fc	0 ALARM2.NO BO 1 ALARM2.BO01   4 ALARM2.BO04   46 ALARM2.BO46   76 ALARM2.BO76	Alarm value 2 to output <u>like alarm value 1</u>	

Loop 1						Function	Rem. S.96	
Module	Query Param.	Response						
11	Q03	D	1	5	fc	0 ALARM3.NO BO 1 ALARM3.BO01   4 ALARM3.BO04   46 ALARM3.BO46   76 ALARM3.BO76	Alarm value 3 to output <u>like alarm value 1</u>	
	Q04	D	1	5	fc	0 ALARM4.NO BO 1 ALARM4.BO01   4 ALARM4.BO04   46 ALARM4.BO46   76 ALARM4.BO76	Alarm value 4 to output <u>like alarm value 1</u>	
	Q05	D	1	5	fc	0 MAN NO BO 1 MAN NO.BO01   4 MAN NO.BO04   46 MAN NO.BO46   76 MAN NO.BO76	Feedback signal manual to output <u>like alarm value 1</u>	
	Q06	D	1	5	fc	0 AUTO NO BO 1 AUTO NO.BO01   4 AUTO NO.BO04   46 AUTO NO.BO46   76 AUTO NICHT.BO76	Feedback signal automatic to output <u>like alarm value 1</u>	
	Q07	D	1	5	fc	0 CASC.NO BO 1 CASC.NO.BO01   4 CASC.NO.BO04   46 CASC.NO.BO46   76 CASC.NO.BO76	Feedback signal cascade to output <u>like alarm value 1</u>	
	Q08	D	1	5	fc	0 WEXT NO BO 1 WEXT NO.BO01   4 WEXT NO.BO04   46 WEXT NO.BO46   76 WEXT NO.BO76	Feedback signal - external set point <u>like alarm value 1</u>	
	Q09	D	1	5	fc	0 PRG.END NO BO 1 PRG.END NO BO01   4 PRG.END NO BO04   46 PRG.END NO BO46   76 PRG.END NO BO76	Program end signal to output <u>like alarm value 1</u>	

Loop 1						Function	Rem. S.96
Module	Query Param.	Response					
11	Q10	D ● ● ● ● ● ● - -	1 ● ● ● - - - -	5 ● ● ● ● ● ● ● ●	fc 0 PRG.BIN1 NO BO 1 PRG.BIN1 NO BO01   4 PRG.BIN1 NO BO04   46 PRG.BIN1 NOBO46   76 PRG.BIN1 NOBO76	Binary track 1 of the programmer to binary output like alarm value 1	
	Q11	D ● ● ● ● ● ● - -	1 ● ● ● - - - -	5 ● ● ● ● ● ● ● ●	fc 0 PRG.BIN2 NO BO 1 PRG.BIN2 NO BO01   4 PRG.BIN2 NO BO04   46 PRG.BIN2 NOBO46   76 PRG.BIN2 NOBO76	Binary track 2 of the programmer to binary output like alarm value 1	
	Q12	D ● ● ● ● ● ● - -	1 ● ● ● - - - -	5 ● ● ● ● ● ● ● ●	fc 0 PRG.BIN3 NO BO 1 PRG.BIN3 NO BO01   4 PRG.BIN3 NO BO04   46 PRG.BIN3 NOBO46   76 PRG.BIN3 NOBO76	Binary track 3 of the programmer to binary output like alarm value 1	
	Q13	D ● ● ● ● ● ● - -	1 ● ● ● - - - -	5 ● ● ● ● ● ● ● ●	fc 0 PRG.BIN4 NO BO 1 PRG.BIN4 NO BO01   4 PRG.BIN4 NO BO04   46 PRG.BIN4 NOBO46   76 PRG.BIN4 NOBO76	Binary track 4 of the programmer to binary output like alarm value 1	
12							
BINARY FLAGS (Function of binary flags in display)							
Q01	D ● ● ● ●	1 ● ● ●	5 ● ● ●	fc 0 ALARM1.NO FLG 1 ALARM1.FLG1   6 ALARM1.FLG6	Alarm value1 Alarm value1 not connected to Flag1 Display with Flag 1   Display with Flag 6		
	Q02	D ● ● ● ●	1 ● ● ●	5 ● ● ●	fc 0 ALARM2.NO FLG 1 ALARM2.FLG1   6 ALARM2.FLG6	Alarm value 2 like query 1	
	Q03	D ● ● ● ●	1 ● ● ●	5 ● ● ●	fc 0 ALARM3.NO FLG 1 ALARM3.FLG1   6 ALARM3.FLG6	Alarm value 3 like query 1	
	Q04	D ● ● ● ●	1 ● ● ●	5 ● ● ●	fc 0 ALARM4.NO FLG 1 ALARM4.FLG1   6 ALARM4.FLG6	Alarm value 4 like query 1	

- 1 In split range mode the G control has effect on both controller outputs. If the parameter variation is not desired in a controller output, the values for G start and G end should be set equally.
- 2 Not for three-position controllers and split range.
- 3 The difference between Lx-B03-P07 and P08 is the reference value for G. The values must lie within the measuring range limits of the analog input. They can match, they can however also deviate. See examples in Section on 'Fixed value control'.
- 4 Only available in the loop in which the programmer was first switched. Configure additionally: PG01-P0x.
- 5 Display in the front require activation of the alarm management for unit: G-B10-Q01 = 1.
- 6 For step controllers.
- 7 OLDMODE = previous operation mode
- 8 Not for Digitric 500.
- 9 For Digitric 500 for scaling the analog output, when Q18 <> 0.
- 10 Not for Digitric 500.
- 11 Invalid for step controllers.
- 12 Changeable but changes eventually lead to faulty displays.
- 13 Only Protronic 550.
- 14 IC3 and IC4 not with Protronic 100.

Loop 2, 4 (Protronic 100: only loop 2)					function	Rem. S.96
Module	Query Param.	Response				
01 CONTROLLER FUNCTION						
Q01	D	1	5	fc	0 NO CONTROLLER	Controller function
	•	•	•	•	1 SINGLE LOOP	Unused
	•	-	•	•	2 MASTER CONTR.	Single-channel controller
	•	•	•	•	3 SLAVE CONTR.	Master controller in cascade
	•	-	•	•		Slave controller in cascade (for 2 slave controllers)
	•	•	•	•	6 OVERR.SL.MIN	Min. override controller adjustment
	•	•	•	•	7 OVERR.SL.MAX	Max. override controller adjustment
	•	-	•	•	8 MANUALSTATION	Single-channel manual station
	•	-	•	•	9 SETPT.STATION	Single-channel set point station
	•	-	•	•	10 RATIO STATION	Single-channel ratio station
	•	-	•	•	11 POSITIONER	Single-channel positioner
	•	-	•	•	12 RAT.STAT.CASC	Ratio station in cascade (only loop 4)
	Q02	D	1	5	fc	1 CONTINUOUS
•		•	•	•	2 STEP CONTR.	K = continuous
•		•	•	•	3 ON/OFF CONTR.	S = step
•		•	•	•	5 H-OFF-C (S+S)	Z = two-position
•		•	•	•	6 H-OFF-C (C+S)	D = three-position heat-o-cool (relay)
•		•	•	•		D = three-position heat (cont.)-o-cool (relay)
•		-	•	•	7 SPLIT.R. (C+C)	KK = split range with 2 continuous outputs
Q03		D	1	5	fc	
	•	•	•	•	1 M-CHAR-DIR	Position display =
	•	•	•	•	2 M-CHAR-INV	0 % 50 % 100 %
	•	-	•	•	3 M:INV-DIR	Z=K off on
	•	-	•	•	4 M:DIR-DIR	on off
	•	-	•	•	5 M:INV-INV	D Out2on Out2off Out1off Out1on
	•	-	•	•	6 M:DIR-INV	= Out2off Out2on Out1off Out1on
					KK Out2on Out2off Out1on Out1off	
					Out2off Out2on Out1on Out1off	
					S depending on the wiring	
						off = permanently off or 0/4 mA;
						on = permanently on or 20 mA
	B01-Q04+Q05 and module 02 to 12 as Loop 1					

1 Cascade with two slave controllers and ratio station (see page 50).

Loop 3 (not Protronic 100)					Function	Rem.	
Module	Query Param.	Response					
01 CONTROLLER FUNCTION							
Q01	D	1	5	fc	0 NO CONTROLLER	Control function Unused	
	•	-	•		1 SINGLE LOOP	Single-channel controller	
	•	-	•		2 MASTER CONTR.	Master controller in cascade for 2 slaves.	
	•	-	•		3 SLAVE CONTR.	Slave controller in cascade	
	•	-	•		6 OVERR.SL.MIN	Override min. override controller adjustment	
	•	-	•		7 OVERR.SL.MAX	Override max. override controller adjustment	
	•	-	•		8 MANUALSTATION	Single-channel manual station	
	•	-	•		9 SETPT.STATION	Single-channel set point station	
	•	-	•		10 RATIO STATION	Single-channel ratio station	
	•	-	•		11 POSITIONER	Single-channel positioner	
	Q02	D	1	5	fc	1 CONTINUOUS	Controller output (not required for Q1 = 6, 7) K = continuous
		•	-	•		2 STEP CONTR.	S = step
•		-	•		3 ON/OFF CONTR.	Z = two-position	
•		-	•		5 H-OFF-C (S+S)	D = three position heat-o-cool (relay)	
•		-	•		6 H-OFF-C (C+S)	D = three-position heat (cont.)-o-cool (relay)	
•		-	•		7 SPLIT.R. (C+C)	KK = split range with 2 continuous outputs	
Q03		D	1	5	fc		Manual characteristic (unnecessary for Q1 = 6, 7)
		•	-	•		1 M-CHAR-DIR	
		•	-	•		2 M-CHAR-INV	
		•	-	•		3 M:INV-DIR	
		•	-	•		4 M:DIR-DIR	
		•	-	•		5 M:INV-INV	
	•	-	•		6 M:DIR-INV		
						Position display =	
						0 % 50 % 100 %	
						Z off on	
						on off	
						D Out2on Out2off Out1off Out1on	
					= Out2off Out2on Out1off Out1on		
					KK Out2on Out2off Out1on Out1off		
					Out2off Out2on Out1on Out1off		
					S   depending on wiring		
						off = permanently off or 0/4 mA; on = permanently on or 20 mA	
B01-Q04+Q05 and module 02 to 12 as Loop 1							

**Note**

The state correction can only be edited, after it has been integrated into the configuration in a loop.

State correction 1/2 (not Prottronic 100)					Function								Rem. p.100		
Module	Query Param.	Response													
01															
TASK															
Q01	D	1	5	fc	State correction										
	•	•	•	•	Unused										
	•	-	•	•	0 UNUSED										
	•	-	•	•	1 GAS ORIF										
	•	-	•	•	2 GAS VOLUM										
	•	-	•	•	3 STEAM,ORI										
	•	-	•	•	4 SATSTEAM,P										
	•	-	•	•	5 SATSTEAM,T										
	•	-	•	•	6 WATER ORI										
•	-	•	•	7 WATER VOL											
•	-	•	•	8 BOIL.LEV.											
	D	1	5	fc	Required parameters for										
					Q01 = >										
					1	2	3	4	5	6	7	8			
P02	Qn-CALCUL Value				Qn, r Qm, r	-	Qm, r	Qm, r	Qm, r	Qm, r	-	-			
P03	dP-CALCUL Value				dP, r	-	dP, r	dP, r	dP, r	dP, r	-	-			
P04	P-atm-CALCUL Value				Patm, r	Patm, r	Patm, r	Patm, r	-	Patm, r	Patm, r				
P05	P-CALCUL Value				Pü, r	-	Pü, r	Pü, r	-	Pü, r	Pü, r	-			
P06	T-CALCUL Value				T, r	-	T, r	-	T, r	T, r	-	-			
P07	Z-CALCUL (P, r; T, r) Value				Z, r	-	-	-	-	-	-	-			
P08	RHO-CALCUL Value				RHOnr	RHOnr	-	-	-	-	-	-			
P10	P-MIN Value				Pmin	Pmin	Pmin	Pmin	-	Pmin	Pmin	Pmin			
P11	P-MAX Value				Pmax	Pmax	Pmax	Pmax	-	Pmax	Pmax	Pmax			
P12	T-MIN Value				Tmin	Tmin	Tmin	-	Tmin	Tmin	Tmin	-			
P13	T-MAX Value				Tmax	Tmax	Tmax	-	Tmax	Tmax	Tmax	-			
P14	RHO-MIN Value				Rho min	Rho min	-	-	-	-	-	-			
P15	RHO-MAX Value				Rho max	Rho max	-	-	-	-	-	-			
P16	DISTANCE Value				-	-	-	-	-	-	-	HAB			
P17	T-REFERENC Value					-	-	-	-	-	-	Tvgl	1		
Q18	0 OVERPRESSURE 1 ABS. PRESSURE				x x	x x	x x	x x	- -	x x	x x	x x			
P20	COMP.COEF Z1 Value				Z(1)	Z(1)	-	-	-	-	-	-			
...	to				...	...	-	-	-	-	-	-			
					1	2	3	4	5	6	7	8			
P28	COMP.COEF Z9 Value				Z(9)	Z(9)	-	-	-	-	-	-			

State correction 1/2 (not Protronic 100)			Function										Rem. p.100
Module	Query Param.	Response											
	Q29	0 LINEAR 1 SQR		-						-	-		
	P30	RANGE LO Value	0	0	0	0	0	0	0	0	Value	0 = pre- set	
	P31	Value RANGE HI	upper range value of the corrected signal corresponds to 20 mA for analog output										
	Q32	0 NO DIM. 1 DIM USER DIM. 7 DIM = m³/h 8 DIM = kg/h 9 DIM = t/h   n	Dimension for AI01 No dimension 4-digit, freely definable Q33 m³/h kg/h t/h   see AI-Bxy-Q03										
	P33	DIMENSION - - - -	Editing of the user dimension if query 32 = 1										
02			ROUTING AI (Routing of the analog inputs to the state correction)										
Q01	D	1	5	fc	1 IFC Q=AI01 2 IFC_Q=AI02   44 IFC_Q=AI44   74 IFC_Q=AI74	Flow measured value, differential pressure when B01-Q01 = 8 AI01 AI02   AI44   AI74							
	•	-	•										
	•	-	•										
	•	-	•										
Q02	D	1	5	fc	0 IFC P CALC 1 IFC P=AI01 2 IFC_P=AI02   44 IFC_P=AI44   74 IFC_P=AI74	Pressure measured value (P) in bar Not used P = Pr AI01 AI02   AI44   AI74							
	•	-	•										
	•	-	•										
	•	-	•										
Q03	D	1	5	fc	0 IFC T CALC 1 IFC T=AI01 2 IFC_T=AI02   44 IFC_T=AI44   74 IFC_T=AI74	Temperature measured value (T) in °C not used T = Tr AI01 AI02   AI44   AI74							
	•	-	•										
	•	-	•										
	•	-	•										
Q04	D	1	5	fc	0 IFC DENS=CALC 1 IFC D=AI01 2 IFC_D=AI02   44 IFC_D=AI44   74 IFC_D=AI74	Density measured value in kg/m³ not used Rho = Rhonr AI01 AI02   AI44   AI74							
	•	-	•										
	•	-	•										
	•	-	•										
03			ROUTING AO (Routing of the result of the state correction on analog output)										
Q01	D	1	5	fc	0 FC1=NO AO 1 FC1=AO01   43 FC1=AO43   73 FC1=AO73	State correction on analog output No output AO01   AO43   AO73							
	•	-	•										
	•	-	•										
	•	-	•										



- 1 Up to version 3.4.0. Afterwards replaced by T-MIN = T-MAX  
= Tvgl or direct measured values. Routing ZKx-B02-Q03.  
Then T-MIN unequal to T-MAX.

## Abbreviations and terms

Index "r" for "calculated values" (values for defining orifice)

Qv	Operating volume flow in m <sup>3</sup> /h
Qn	Volume flow in standard condition in m <sup>3</sup> /h
Qm	Mass flow in standard condition t/h
P	in absolute bar or overpressure (depending on the transmitter)
Pr	in absolute pressure
T	Temperature in °C
Pn	Standard pressure 1.0135 bar
Tn	Standard temperature 273,15 K = 0 °C
RHO	Density in kg/m <sup>3</sup>
RHO-MIN	Correction range for RHO
RHO-MAX	Correction range for RHO
Patm	atmospheric pressure in absolute bar
Pr	in absolute bar
Zn	Real gas factor for Pn and Tn (compressibility figure)
Pmin/Pmax	Correction range for P (according to transmitter)
Tmin/Tmax	Correction range for T
P20...28	Real gas factors (factory setting 1.00) (compressibility figure)

	Tmin	Tmitte	Tmax
Pabsmin	P20	P23	P26
Pabsmitte	P21	P24	P27
Pabsmax	P22	P25	P28

HAB	Nozzle spacing in mm produces water level in mm.
Tvgl	Temperature of the reference column in °C (up to version 3.4.0. After that replaced by T-MIN = T-MAX = Tvgl or direct measured value. Routing ZKx-B02-Q03. Then T-MIN unequal to T-MAX).

## Notice

The programs can only be edited, when the programmer has been activated as set point source in a loop (Lx-B05-Q08 = 1).

Programmer						Function	Rem.
Module	Query Param.	Response					
01						PROGRAMMER	
1	D	1	5	fC	0	PROGR1=OFF	Program 1
	•	•	•		1	PG1-START SP0	Not activated, without function
	•	•	•		2	PG1-START PV	Start at programmed value
	•	•	•				Start at instantaneous value
					Program 2 to 9		
10	D	1	5	fC	0	PROGR10=OFF	Program 10
	•	•	•		1	PG10-START SP0	Not activated, without function
	•	•	•		2	PG10-START PV	Start at programmed value
	•	•	•				Start at instantaneous value

# Fault messages

## Unit fault messages

When reading or writing in the non-volatile flash memory (all controllers) or in the memory card (only Protronic 500/550), faults can occur. These are reported in the upper text line of the display as

!Fault ....

Instead of the four dots, the fault number of the particular fault will be stated (4-digit). Table 10 gives information on the cause and eventual remedy of the faults involved. The input "xy" in a fault number refers to Table 11 on page 99, which provides more exact details on the faults.

It can happen that a fault cannot be remedied, despite the information provided for remedy. In such case, the manufacturer should be informed, supplying the following details:

- unit version,
- firmware version,
- IBIS\_R/IBIS\_R+ version,
- action already undertaken,
- configuration,
- project and
- fault number.

## Fault messages

Fault number	Fault description	Remarks on fault remedy
32	faults have occurred during download of a configuration	reset unit to factory setting and restart the downloading of the configuration after approximately 2 minutes
3100	insufficient flash memory available for storing a configuration	reset unit to factory setting and restart the downloading of the configuration after approximately 2 minutes or reduced configuration and restart the download exercise
3200 3201	internal computing process is incorrect	inform the manufacturer
40xy	a fault has occurred during the storage of back documentation information	after approximately 2 minutes of configuration without reverse documentation information, restart the download
41xy	a fault has occurred during the storage of the project head	inform the manufacturer
42xy	a fault has occurred during the storage of the list configuration	inform the manufacturer
43xy 44xy	a fault has occurred during the storage of the project version data	inform the manufacturer
45xy	a fault has occurred during the storage of the hardware configuration	inform the manufacturer
46xy	a fault has occurred during the storage of the self-tuned variables.	inform the manufacturer
47xy		
48xy	a fault has occurred during the storage of changes made on the online parameters	inform the manufacturer
49xy		
60xy	the reverse documentation cannot be read	reset unit to factory setting and restart the downloading of the configuration again, if the error persists, let the Flash-memory be exchanged by the manufacturer

Fault number	Fault description	Remarks on fault remedy
61xy	the project head cannot be read	as 60xy
62xy	the list configuration cannot be read	as 60xy
63xy	the project version data cannot be read	as 60xy
64xy		
65xy	the hardware configuration cannot be read	as 60xy
66xy	the self-tuned variables cannot be read	inform the manufacturer
67xy	the free configuration cannot be read	as 60xy
68xy	the changes in the online parameters cannot be read	as 65xy
69xy		
80xy	general hardware fault	let manufacturer conduct maintenance
81xy	flash memory cannot be initialized completely	as 65xy
82xy	due to grave fault in the flash memory, this has been completely deleted	as 60xy
83xy 84xy 85xy 86xy 87xy		

Tab. 13 Instrument error messages

- 1 During download of a configuration, it can take up to 2 minutes until the data is stored in the failproof flash memory. In case of power failure during this time, not all configuration parts will be found upon starting.

## Fault legend

xy	Fault description (refers to flash memory in unit)
0	CRC error when reading a block
1	no free block is found during writing
2	an invalid block number is output during a function call-up
3	a much bigger address offset is stated during a function call-up
4	the flash memory is faulty
5	the flash memory is not available
6	(memory) block not found
7	the stated files were not found
8	(memory) block cannot be deleted
9	power failure
10	power failure during initialization
20	(memory) block content cannot be deleted
21 - 24, 29	incorrectible errors have been made during writing
26	type of memory card invalid
27, 35	no memory card found
28	write protection for memory card active
30	no free storage space available
31 - 34, 36, 39	internal fault
37	read file on memory card is faulty
38	required utility is not available

Tab. 14 Fault legend

## Fault messages in the controller self-tune mode

The fault is output in the form

**S.Par.Err.X**

Here is X the fault numbers 1 to 5:

Fault number	Faulty behaviour	Recommendation
1	<b>general errors</b> the conditions for a fault-free processing of the self-tune mode are not provided, however, it cannot be clearly determined, if there is any faulty behaviour	restart the self-tuning exercise
2	<b>rauschband</b> the <i>rauschband</i> determined by the unit itself at the beginning of self-tuning has turned out to be too small in the course of the self-tuning exercise, this is then the case when interferences greatly increase during self-tuning	restart the self-tuning exercise
3	<b>change of control variable</b> to be able to analyse the controlled system behaviour, there is too little movement in the controlled system	the definable output variable change should be increased
4	<b>time overflow</b> in the controlled system, no movement was determined for a period of 10 hours	the measured value wiring and configuration should be checked for errors, if there are no errors, then the controlled system cannot be identified, due to a too great dead time
5	<b>no relaxation</b> within a time window, no relaxation of the controlled system can be perceived, a stationary condition of the controlled system is however necessary for identification	exit the self-tune mode and switch the control loop to "Manual", wait until the controlled systems no longer show any "visible" movements, restart the self-tuning exercise
6	only for Selftune2	

Tab. 15 Error messages of the controller self-tune mode

## Error messages of the input/output level

On switching on the supply voltage, the unit checks the calibration data for the inputs and outputs. If during this, errors are discovered, these are output in clear text.

Error text	Error description	Remarks for error remedy
E_AI01CONF 3	at least one calibration of AI01 has infringed upon the lower alarm threshold only the values required according to configuration AI01-Q01 are checked here	configured mA- or thermocouple input, the signal transmitters can be recalibrated by way of the front panel, in case of Pt100 input, the calibration must be made by the manufacturer
E_AI01CONF 4	at least one calibration value of AI01 has infringed upon the upper alarm threshold only the values required according to configuration AI01-Q01 are checked here	as E_AI01CONF 3
E_AI02CONF 3	at least one calibration value of AI02 has infringed upon the lower alarm threshold	since AI02 can only be configured as mA input, it can be recalibrated via the front panel with the appropriate signal transmitters
E_AI02CONF 4	at least one calibration value of AI02 has infringed upon the upper alarm threshold	as E_AI02CONF 3
E_BIOCONF 3	at least one calibration value from BIO01 to BIO04 has infringed upon the lower alarm threshold	the calibration must be done by the manufacturer
E_BIOCONF 4	at least one calibration value from BIO01 to BIO04 has infringed upon the upper alarm threshold	as E_BIOCONF 3

Tab. 16 Error messages of the input/output level

# Index

## A

Abort of self-tune mode	17
Acceptance of parameters	17
Activate programs	18, 28
AI definition	18, 23, 79
Air control	50, 84
Alarm management	8, 76
Alarms	13, 70, 71, 89
Analog.0%	85
AO definition	18, 81
Automatic characteristic	26

## B

Background illumination of LCD	56
Balancing	25, 48, 57, 58
Balancing of Pt100	57
Balancing of teletransmitter	58
Binary flags	75, 93
Binary inputs	5, 75, 89
Binary outputs	5, 47, 76, 93
BIO definition	18, 81
Brightness of LED	56

## C

Cascade control with two slave controllers and ratio station	49
Cascade with two slave controllers	49, 96
Cascade with one slave controller	49
Cascades	30, 33, 35, 49
Characteristics	26
Classification of the configuration tables	18
Combustion control: air control	50
Communication	76, 78
Computer ready	92
Computer set point	27, 35, 87
Configuration	2, 5-7, 12, 18-20, 27, 28, 30, 31, 33-36, 38, 40-42, 49-53, 57, 62, 63, 86, 98
Configuration change	19
Configuration examples	21
Configuration menu	5, 15, 18, 20, 21, 28
Configuration menu exit	20
Configuration tables	2, 7, 18, 21, 75
Continuous controller	2, 7, 48
Contrast LCD	56
Control jump	15, 71
Controller function	82, 96, 97
Controller parameters	82
Controller output	6, 12, 16, 31, 47-49, 69, 82, 92, 96, 97
Correction task	98
Cumulative flow	34

## D

Dead time	12, 53, 68, 82
Dead time, Smith Predictor	53
Dimension	6, 12, 24, 30, 31, 36, 38, 43-46, 79, 84, 85, 99
Display	5, 73
Display optics	56
Disturbance variable	51, 83, 84
Disturbance variable feedforward	13, 31, 51, 71, 83
Drum water level	33, 42, 46
Drum water level control in cascade	51

## E

End value balancing	58
Error details	103
Error messages	101
Error messages of self-tune mode	104
Error messages of the input/output level	105
Extreme value	84

## F

Factory setting	2, 15, 27, 42, 43, 62, 65, 67, 72-75, 78-80, 85, 100
Filtering	18, 24
Fixed value	30, 32, 35, 36, 38, 39, 46, 48, 51, 84, 86
Fixed value control	30, 31, 35, 96
Front panel	6

## G

Gas differential pressure measurement	43, 44
Gas flow	98
Gas volume measurement	43, 44
Gases and steam	42

## H

Hardware	9, 22, 54, 75
Heat quantity control	40

## I

Information, general	54
Information, hardware	54
Input circuitry	84
Input ratio	13, 89
Input weighting values	13

## L

Λ Control	36
Language	5, 75
Linear	25, 33, 36, 41, 44, 79, 83, 84, 99
Loop 1	12, 18, 49-51, 67, 82, 84, 96, 97
Lost password	9

## M

mA Inputs	25
Manual characteristic	26, 82, 96, 97
Master controller	52, 67, 82
Manual station	82, 96, 97
Max. jump duration	15
Max. neg. control deviation	15
Max. pos. control deviation	15
Memory card	63
Menu system	7, 13, 20
Min.- or max. selection	52
Mixture control	37, 38
Modul default	76
Module assignment	76
Multi-components	33, 34, 84
Multi-component control	33, 51
Multiplication	40, 84, 85



## N

Neutralisation control	37
Non-linear	36, 41
Notices	2, 5, 14
Numbering	5

## O

Operating modes	6, 88, 91
Override control	47, 52, 96, 97

## P

Parameter	5, 7, 11-13, 15-17, 19, 22, 27, 28, 35, 36, 40-42, 47, 50, 53, 65, 67, 68, 71-73, 83, 86, 92, 93, 98
Parameter changeover	5, 41
Parameter control	12, 31, 41, 67-69
Parameter definition	2, 5-7, 10, 12, 14, 16, 17, 19, 41, 50, 53, 63, 65, 82
Parameter definition level	10, 11
Parameter definition of Loop 1 to 4	12
Parameter level exit	13
Parameter variation	41, 96
Parameter selection and change	11
Parameter tables	5, 12, 65
Parameter unit	12
Password	9, 11, 22, 64, 78
Password delete	64
Password input	9, 22
Password protection	9, 22, 78
PID parameter	12, 67
PID2 parameter	12
Plausibility check	20, 61, 62
Positioner	47, 48, 82, 96, 97
Parameter-define programs	28
Programmer	3-6, 12, 18, 27-29, 35, 72, 100

## R

Ratio 1	37, 38, 70, 84
Ratio 2	37-39, 70, 84, 85
Ratio control	35-37, 70
Ratio input signal connections	35
Ratio set point	27
Ratio station	82
Reject the parameters	17
Remote control	6, 75
Resistance thermometer input	25
Routing_es	86
Routing_y	92
Routing of the inputs and outputs	42

## S

Saturated temperature correction	44, 98
Saturated steam	43, 44, 98
Saturated pressure correction	44, 98
Selection of configuration menu	18
Self-tune mode	7, 12, 14-17, 71
Sensor fault	24, 80
Service	7, 9, 25, 48, 54, 58
Set point ramp	27, 70
Set point station	82
Set points	6, 12, 27, 35, 50, 70, 86
Set point 1	27, 35, 70, 86, 87
Split range	48
Start of self-tune mode	15
State correction	3-5, 18, 30, 31, 33, 40, 42, 46, 83, 86, 98, 99
State correction 1/2	98
Steam-mass-flow	43, 44
Step controller	47, 48, 82, 92, 93
Supervisor	7, 61
Supply condition	2
Switch-on of unit	2

## T

TAG name	13
Tank water level	98
Teletransmitter input	25
Thermocouple input	25
Three-position controller (heat - off - cool)	47
Tie point value	65
Transistor output	47
Two-position controller	47
Two-position controller for powerful-weak-off	47

## U

Unit	2-5, 7, 9, 10, 12, 14, 15, 18, 20-23, 27, 28, 42, 64, 65, 75, 76, 78, 80, 86, 96
Unit error messages	101

## W

Water mass flow	42, 45, 98
Water mass flow - differential pressure	98
Water mass flow - volume measurement	98

## Z

Zero-point balancing	58
----------------------	----

# General menu overview




Fig. 95 General menu overview

Subject to technical changes.

This technical documentation is protected by copyright. Translating, photocopying and disseminating it in any form whatsoever - even editings or excerpts thereof - especially as reprint, photomechanical or electronic reproduction or storage on data processing systems or networks is not allowed without the permission of the copyright owner and non-compliance will lead to both civil and criminal prosecution.



---

**ABB Automation Products GmbH**  
Höseler Platz 2  
D-42579 Helligenhaus  
Tel. +49(0)20 56 12 - 51 81  
Fax +49(0)20 56 12 - 50 81  
<http://www.abb.com>

Subject to technical changes.  
Printed in the Fed. R. of Germany  
42/62-50012 EN Rev. 06  
Edition 03.01

# Control<sup>IT</sup>


## Process controller P100/500

(Protronic 100/500)

Versatile controller with powerful PLC functionality,  
extensible with hardware modules

**Industrial<sup>IT</sup>**  
enabled

---



**PROFIBUS**

---

# ABB

# Process controller P100/500 (Protronic 100/500)

Versatile controller with powerful PLC functionality,  
extensible with hardware modules

## User Manual

Document No. 42/62-50013 EN

Date of issue: 07.03

Revision: 05

## Manufacturer:

ABB Automation Products GmbH  
Hoeseler Platz 2  
42579 Heiligenhaus  
Germany

Tel: +49 2056 - 12-5181

Fax: +49 2056 - 12-5081

© Copyright 2003 by ABB Automation Products GmbH  
We reserve the right to technical amendments

This document is protected by copyright. Information in this document is intended only to assist the user in safe and efficient operation of the equipment. Its contents are not to be reproduced in full or part without prior approval of legal owner.

Content	Page
<b>Preface</b>	5
<b>Delivery state</b>	5
<b>Switching on the device</b>	5
<b>1 Important information in advance</b>	6
1.1 Symbols	6
1.2 Conventions used in these user manual	6
<b>2 Application according to designation, general safety instructions</b>	7
2.1 Range of application, application according to designation	7
2.2 Safe operation	7
<b>3 Operation</b>	9
3.1 Operating elements on the P100/500 front panel	9
3.2 LC-Display	10
3.3 Alarm handling	11
3.4 Channel switching	11
3.5 Automatic mode (A)	11
3.6 Manual mode (M)	12
3.7 Setpoints	12
3.8 Ratio controller	13
3.9 Programmer	14
3.9.1 Selecting the program	14
3.9.2 Starting the program	14
3.9.3 Displays during program execution	14
3.9.4 Stopping the program	15
3.9.5 Fast forward/backward	15
3.9.6 Resetting (cancelling) the program	15
3.10 Cascade control	16
3.10.1 Cascade with one slave controller	16
3.10.2 Cascade with several slave controllers (not P100)	17
3.10.3 Combustion control (not P100)	19
3.11 Override-control	20
3.12 DDC-Control (Direct Digital Control)	21
3.13 Stations	22
3.13.1 Manual station	22
3.13.2 Setpoint station	22
3.13.3 Ratio station	23
3.13.4 Positioner	23
3.14 Remote control (Profibus or Modbus)	23
<b>4 Error information on the display</b>	24
<b>5 Menu structure</b>	25
5.1 Indication 2	26
5.1.1 Inputs/outputs	26
5.1.2 Parameter display	27
5.1.3 Effective PID parameter	27
5.1.4 Identification	27
5.1.5 Library identification	27
5.1.6 Version display	28
5.2 Operate 2	28
<b>6 Password protection</b>	29
<b>7 Index</b>	30





## Preface

The documentation included in the P100/500 (Protronic 100/500) package consists of the following parts:

Commissioning Instructions P100/500 (Protronic 100/500)	42/62-50011
Configuration Instructions P100/500 (Protronic 100/500)/ D500 (Digitric 500)	42/62-50012

<b>User Manual P100/500 (Protronic 100/500)</b>	<b>42/62-50013</b>
---	--------------------

Also available on request:

User Manual IBIS-R, List Configuration	42/62-50020
User Manual IBIS-R, Free Configuration	42/62-50030

The User Manual in this manual include all important information for menu-guided configuration and parameterization of the device. All necessary entries can be made locally via the device's front panel operating elements, or remotely from a PC with the IBIS-R configuration and parameterization program.

The configuration options of the device menu are also available in the IBIS-R program. The description of this program is beyond the scope of this user manual.

## Delivery state

The devices are delivered off stock and without customized settings. The factory setting is adjusted to the following functions:

- Single-loop continuous controller
- Input: 4...20 mA
- Output: 4...20 mA
- Language: German

The factory setting and its definitions are described in detail in this user manual.

Customized versions are available upon special request.

## Switching on the device





Upon power-on or return of the power after power failure the device automatically performs a selftest of the internal functions. The progress of the test program can be seen on the display. Usually, no special attention has to be paid to this display.

### 1 Important information in advance

#### 1.1 Symbols

To ensure optimum use of these user manual and a safe use of the assemblies during commissioning, operation and maintenance, please observe the following explanations regarding the symbols used.

Explanations of symbols used.

	<b>Warning</b>	Indicates a risk or potentially hazardous situation which, if not avoided, could result in death or serious injury.
	<b>Caution</b>	Indicates a potentially hazardous situation or alerts against unsafe practices which, if not avoided, may result in injury of persons or property damage.
	<b>Notice</b>	Indicates a potentially harmful situation which, if not avoided, may result in damage of the product itself or of adjacent objects.
	<b>Important</b>	Indicates useful hints or other special information which, if not observed, could lead to a decline in operating convenience or affect the functionality.

Apart from the information in these user manual you must also observe commonly valid safety and accident prevention directives.

If the information contained in these user manual is not sufficient for an application our service organisation will gladly be at your disposal for further information.

Please read these assembly and user manual carefully prior to installation.

#### 1.2 Conventions used in these user manual

<Enter> Keys on the device, with their labels  
 <Ind>, <Loop>  
 <Menu>, <Enter> Keys available at all times for operator actions.



P-W, A

/B/

M●, A●, C●

Menu●, Enter●

M○, A○, C○

Menu○, Enter○

Sxt

Hand

Flashing texts or text fragments from the digital display

Texts or text fragments from the digital display

Reference to numbers in Fig. 3-1

Light-emitting diodes (LEDs) alongside the keys with the same name are lit.

Light-emitting diodes (LEDs) alongside the keys with the same name are lit.

Light-emitting diodes (LEDs) alongside the keys with the same name are not lit.

Light-emitting diodes (LEDs) alongside the keys with the same name are not lit.

External setpoint source

Operating mode

### 2 Application according to designation, general safety instructions



**Important instructions for your safety!**  
Please read and observe.

#### 2.1 Range of application, application according to designation

P100 (Protronic 100) is a 1-loop compact controller (2nd loop cascade and override)  
P500 (Protronic 500) is a 1...4-loop compact controller.

The devices are designated for the instrumentation of single control loops and for automating small and medium-sized processes in control engineering.

For proper use it is required to observe the „Technical Data section “ in the Data Sheets. You will find the technical data in the data Sheets 10/62-6.11 (P100) and 10/62-6.15 (P500).

Any other use is considered improper.

#### 2.2 Safe operation

The technology of the devices is state of the art.

The devices are constructed and tested according to EN 61 010-1 = IEC 1010-1 = DIN VDE 0411 Part 1 "Safety Requirements for Electronic Measurement Apparatus" and have left the factory in a safe condition. To maintain this state and guarantee hazard-free operation, all safety instructions in this manual headed by "Warning, Caution or Notice" must be observed.

Otherwise, personnel might be endangered and the mass flow meter itself or other devices and equipment could be damaged.

These user manual contain important information about the safe and proper operation of the equipment. Observing these instructions is mandatory for safe operation. Failure to observe the instructions can cause hazards for life and limb of the user respectively property damages at the devices or the entire system.

Proper and safe operation of the mass flow meter requires proper transportation and storage, installation and commissioning by qualified personnel, operation within its design limits, and careful maintenance observing all information in these user manual.

**Prerequisites for safe operation.**

**Qualification of personnel**

**Operator**

Only personnel familiar with the installation, commissioning, and maintenance of similar devices and having the required qualifications for their tasks are allowed to work on the device.

The operator of the plant is fully and solely responsible for proper and workmanlike and, thus, safe operation.

The operator must make sure that the user manual have been understood by the target audience.

A copy of the user manual must be stored in a suitable place at the usage location of the device at all times.

Read these user manual prior to commissioning, decommissioning, maintaining, or repairing a device.

**National regulations**

The regulations, standards, and guidelines mentioned in these user manual are valid for Germany. When using the devices in other countries the appropriate and valid national regulations must be observed.

**Notes and regulations to be observed**

Observe

- the contents of these user manual and references to other documents and their contents
- the safety regulations affixed to the device
- the appropriate and valid safety instructions for the construction and operation of electrical systems
- the regulations and directives regarding explosion protection.

**During operation**

The operator must commission a qualified electrician to inspect and examine the system at defined intervals. The examination intervals must be chosen in such a way that any damages that can be expected can be recognised in time.

The examinations must be performed at least every three years.

The examinations can be skipped if the electrical system is continuously monitored by a responsible engineer

Duties of the operator:

- maintain the system in proper condition
- continuously monitor the system
- execute required maintenance and repair work immediately
- carry out required safety measures

If the devices are used in areas where dusts can cause explosion hazards, you must clean the devices frequently.

Use genuine spare parts, only.

## 3 Operation

### 3.1 Operating elements on the P100/500 front panel




Fig. 3-1 Front panel P100/500 (Protronic 100/500)


- 1 Text line
- 2 Digital indicator for process value PV
- 3 Designation of the process value
- 4 Dimension of the process value
- 5 Digital indicator: indicates setpoint SP in automatic mode and output value OUT in manual mode
- 6 Designation of the indicated value
- 7 Dimension of the value indicated value
- 8 Number of the control loop displayed, interchanges with display „A“ if alarm is output
- 9 Indicator for programmer activity
- 10 Remote control indicator
- 11 Configurable binary messages (flags)
- 12 Analog display for controlled variable PV
- 13 Analog display for set point SP
- 14 Setpoint changeover (see chpt. „Setpoints“)
- 15 Button for incrementing the values indicated in 5, 6 and 7
- 16 Toggle switch for indicators 5, 6 and 7
- 17 Button for decrementing the values indicated in 5, 6 and 7
- 18 Loop transfer switch
- 19 Mode switch for selecting manual or automatic mode, with indicator LEDs
- 20 Button for accessing the configuration or parameterization level  
The appropriate LED lights up as soon as the operator control level is exited; at the same time menu symbol is visible in the text line
- 21 Button for alarm acknowledgement and confirmation of data (configuration and parameters)
- 22 Up button for incrementing in manual mode
- 23 Down button for decrementing in manual mode
- 24 Analog display for controller output „OUT“
- 25 Screw for fastening display/keypad

The numbers of the individual control and display elements are used consistently throughout the device documentation.

## 3.2 LC-Display

The values seen in the "2nd line" column of the table below can be accessed in two different ways:

1. From left to right:  
Press <Ind> button (several times).
2. From right to left:  
Press and hold <Ind> button



Input circuit/ function		1st line	2nd line Controller									Programmer	
Fixed value (FV)		PV	SP1-SP4		Sxt	SPC	P0x	–	Err	OUT	ALi	PS	PGt
Multi components		PV	SP1-SP4		Sxt	SPC	P0x	–	Err	OUT	ALi		
Multiplication		PV	SP1-SP4		Sxt	SPC	P0x	–	Err	OUT	ALi		
Ratio (RPV, SR)		RPV	SR1-SR3		Rxt	SRC	P0x	SR	Err	OUT	ALi		
Ratio (PV,SR*IC2)		PV	SR1-SR3		Rxt	SRC	P0x	SR	Err	OUT	ALi		
Fixed value/Ratio  (RPV, SR)	FV	RPV	SP1	SR1- SR3	Rxt	SRC	P0x	SR	Err	OUT	ALi		
	Ratio	RPV	SP1	SR1- SR3	Rxt	SRC	P0x	SR	Err	OUT	ALi		
Fixed value/ratio  (PV, SR*IC2)	FV	PV	SP1	SR1- SR3	Rxt	SRC	P0x	SR	Err	OUT	ALi		
	Ratio	PV	SP1	SR1- SR3	Rxt	SRC	P0x	SR	Err	OUT	ALi		
Extreme value (Max, Min, PV, SP)		PV	SP1-SP4		Sxt	SPC	P0x	–	Err	OUT	ALi		
Load control – air		same as ratio											
Load control – fuel		same as fixed value											
Manual station		PV	–	–	–	–	–	–	–	OUT	ALi	–	–
Setpoint station		–	SP1-SP4		Sxt	SPC	P0x	–	–	–	–	PS	PGt
Ratio station		PV	SR1-SR3		Rxt	SRC	P0x	SR	–	–	–		
Positioner		PV=OUTfb	SP1-SP4		Sxt	SPC	P0x	–	Err	OUT	ALi		

Table 3-1 Grayed indicators flash. These values are only displayed, but are currently not active.

PV	Measured value (with ratio control: measured value in the quotient numerator)
SP1-SP4	Setpoints 1 to 4
SR1 - SR3	Ratio setpoints 1 - 3
Sxt, Rxt	External setpoint
SPC, SRC	Computer setpoint
P0x	Programmer setpoint (indicated as P01 to P10)
IC2	With ratio control: measured value in the quotation denominator
SR	Setpoint active during ratio control ( $R \cdot IC2$ ) or $(R \cdot IC2)/(1-R)$
Err	Control deviation
OUT	Controller output
OUTfb	Position feedback
ALi	Alarm limits AL1 to AL4, if enabled
Programmer:	
PS	Currently executed program segment PS
PGt	Program run time since startup

Setpoints are only indicated when they are enabled in the configuration.

### Display color switchover

All Controllers P100 and P500 with a negativ display (illuminated signs on a dark background, new since July 2003) allow to switch the color of the display between red and green if the firmware of the controller is V1.206 or later. The switchover has to be done in the menu. First of all you have to navigate to any subitem of „Service/Display Unit“ (if you see at the „Display Unit“ you must press once „Enter“).

If you are in this subitems and you press the keys <LOOP> and <IND> at once, the color will immediatelly change. The adjusted color will be stored on non volatile memory.

In the future software library 3.70 (controller firmware 1.3xx or later) the color switchover will be realised as separat item in the menu. The description for this will then be written in the configuration manual.

## 3.3 Alarm handling




Fig. 3-2 Alarm message  
z-19000




Fig. 3-3 Alarm value is set to 1000.0  
z-19001

When an alarm or error occurs or an alarm value is exceeded during an operating cycle,

- a flashing "A" appears in the bottom right corner of the display,
- the error or alarm source is indicated in the first line of the display instead of the TAG name,
- the <Enter> LED is lighted.

### Note

Unconfirmed operating instructions displayed in the text line have priority over error codes. As long as the operating instruction is still unconfirmed, the alarm is only indicated by the flashing "A". Alarm acknowledgement is not possible in this situation!

### Displaying the exceeded alarm value

Press <Ind> to display the alarm value.

### Acknowledging the alarm

press <Enter> (standard configuration):

#### *If there is no other alarm:*

The display is reset and the normal values are indicated.

The LED is extinguished, whether the alarm is still active or not.

#### *If there are other alarms*

More alarms are indicated in the same way as described above and have to be acknowledged individually.

## 3.4 Channel switching

If several controllers are configured in one device, <Loop> can be used to switch the control cycles. There are up to 4 Loops (P100 max. 2 loops).

## 3.5 Automatic mode (A)

### Possible operator actions

When the controller is switched over from manual to automatic mode, the active setpoint is seen on the digital indicator. Other values can be selected by pressing the <Ind> button.

<M/A/C>	Switch over from manual to automatic mode
<SP-w>	Switch over the setpoint (if configured)
<▼> <▲>	Increment/decrement the setpoint
<Menu>	Switch over to another menu level

### 3.6 Manual mode (M)




Fig. 3-4 Output OUT is indicated  
z-19020

The functions of the  $\triangle$  and  $\nabla$  buttons are defined either through configuration or, in case of the step controller, through the appropriate wiring. Usually, a more critical state - e.g. a higher furnace temperature - is reached by pressing the  $\triangle$  button.

After the controller has been changed over from automatic to manual mode, the output variable OUT is shown by the digital indicator. Other values can be selected by pressing the  $\triangle$  button.

In the case of controllers with double output (split range or heating-off-cooling) the display 0...100% corresponds to the full output range of both outputs.

Example:

Heating-off-cooling (with normal characteristic curve)

OUT = 0 % corresponds to 100 % cooling

OUT = 50 % corresponds to 0 % cooling and 0 % heating

OUT = 100 % corresponds to 100 % heating

#### Possible operator actions

$\triangle$ $\nabla$ $\triangle$ $\nabla$	Increment/decrement the output signal
Press and hold $\triangle$ , additionally press $\triangle$ $\nabla$	control output jumps to end value -5 %
Press and hold $\triangle$ , additionally press $\triangle$ $\nabla$	control output jumps to end value +105 %
$\nabla$ $\triangle$	SP indicator: increment/decrement the setpoint
$\triangle$ M/A/C	Switch over between manual, automatic mode, cascade
$\triangle$ SP-w	Switch over the setpoint (if configured)
$\triangle$ Menu	Select another menu level


### 3.7 Setpoints

The  $\triangle$  SP-w button can be used to toggle between several setpoint sources, provided that the controller has been configured accordingly.


Possible setpoint sources are:

- setpoints SP1 to SP4 (or ratio setpoints SR1 to SR3) that can be selected on the device by pressing the  $\triangle$   $\triangle$  or  $\triangle$   $\nabla$  button or
- an external setpoint Sxt (Rxt) via analog input
- or
- a computer setpoint SPC (SRC) via serial interface
- or
- a programmer with 10 programs P01 to P10

Display in field /6/:



For ratio control:



Unconfigured setpoints are suppressed.

Pressing the  $\triangle$  SP-w button will call up the current setpoint for display by the digital indicator, independent of the number of available setpoints.

The setpoint is indicated immediately, but first flashes and becomes active with a delay of 3 seconds. This means that only the last setpoint selected becomes active when the setpoints are switched over quickly.



### 3.8 Ratio controller




Fig. 3-5 Ratio control  
z-19068




Fig. 3-6 Display RPV and SR1,  
SR1 is adjustable

The ratio controller controls

$$RPV(\text{ratio process value}) = SR(\text{set ratio}) = \frac{\text{FlowA}}{\text{FlowB}}$$

or, depending on the configuration,

$$RPV = SR = \frac{\text{FlowA}}{\text{FlowA} + \text{FlowB}}$$

The ratio controller can output the actual ratio to an analog output (0/4...20 mA) if configured accordingly.

When the RPV and SR displays are configured, the ratio setpoint is indicated in the fields /5/, /6/ and /7/ of the digital indicator and can be set.

If configured accordingly, several setpoint sources (SR1 to SR3, Rexternal or program generator) can be selected by pressing the <SP-w> button.

The measured actual ratio is indicated in the fields /2/, /3/ and /4/.




Fig. 3-7 Process value PV= flow A  
and SP = setpoint flow A  
z-19019




Fig. 3-8 SR1 is adjustable  
z-190051






When the PV and SP displays are configured, the calculated setpoint of flow A is indicated in the fields /5/, /6/ and /7/.

The fields /2/, /3/, /4/ indicate the measured actual value of flow A.

Press the <Ind> button to call up the SR1 value in the display fields (/5/, /6/, /7/) and then change it.

### 3.9 Programmer

A programmer can be configured in the controller. Up to 10 different programs with 15 segments each can be saved. Refer to „Configuration instruction“ 42/62-50012 for details about setting the values.

 <p>Fig. 3-9 Program has been selected, but not yet started z-19002</p>	<h4>3.9.1 Selecting the program</h4> <p>If the programmer is configured, the [Pxy] display can be selected by pressing the &lt;SP-w&gt; button. The flashing Pxy display indicates the number of the currently selected program.</p> <p>Press &lt;▲&gt; or &lt;▼&gt; to toggle between up to 10 saved programs (P01 to P10).</p>
 <p>Fig. 3-10 Start ? z-19004</p>	<h4>3.9.2 Starting the program</h4> <p>Once the Pxy display has stopped flashing, the program can be started by pressing the &lt;Enter&gt; button. The question if the program is to be started appears for 3 second in the text line. Confirm with &lt;Enter&gt;. The question mark is replaced with an exclamation mark for a few seconds. If the selection is not confirmed with &lt;Enter&gt; within 3 seconds, the selection is ignored and program selection is enabled again.</p>
 <p>Fig. 3-11 Displaying the current program setpoint 300,0 °C z-19006</p>  <p>Fig. 3-12 Program is in the 11th segment z-19007</p>  <p>Fig. 3-13 Program run time so far 2h:17min:02s z-19008</p>	<h4>3.9.3 Displays during program execution</h4> <p>Press the &lt;Ind&gt; button to switch over the display, either while the program is being executed or after it has stopped. Besides the current setpoint the following items can be indicated:</p> <ul style="list-style-type: none"> <li>– Program segment</li> <li>– Program run time.</li> </ul>




Fig. 3-14 Question: Stop program ?  
z-19009




Fig. 3-15 Programmer has stopped.  
Program (Prgm) is flashing.  
z-19011




Fig. 3-16 Fast forward indication  
z-19012




Fig. 3-17 Fast backward indication  
z-19013




Fig. 3-18 Question: Reset?  
z19014




Fig. 3-19 During running program switching  
to other setpoints is not possible  
z19016

### 3.9.4 Stopping the program

When the <Enter> button is pressed again once the program is running, the question for the system stop seen here appears.

When the question is answered with yes by pressing the <Enter> button, a confirmation is shown for 3 seconds.

The program is stopped, and the [Prgm] indicator flashes. The question mark is replaced with an exclamation mark for a short time to confirm.

### 3.9.5 Fast forward/backward

When a program has been stopped, a fast forward/backward run can be achieved by pressing the <▲> or <▼> button. Actuating the <▲> button will shift the program forward to values later in time. When this button is pressed, the fast forward action is confirmed in the display.

How far the program has run forward can be derived from the setpoint, the segment indicator or the time indicator.

A fast backward run of the program can be started by pressing the <▼> button.

### 3.9.6 Resetting (cancelling) the program

If a program is restarted after it has been run down completely, it starts automatically in the 1st segment. No reset is required in this case.

A stopped program can be reset or cancelled by pressing the <SP-w> button.

If the question is answered with yes by pressing the <Enter> button within 3 seconds, the program is reset to the start. The message "Reset!" appears for a short time.

If the operator attempts to switch during a running program to another setpoint (e.g. SP1) by actuating the <SP-w> button, the warning "Program runs" appears in the display for 3 seconds, see Fig. 3-19.

### 3.10 Cascade control

#### 3.10.1 Cascade with one slave controller




Fig. 3-20 Cascade with a slave controller




Fig. 3-21 Slave controller TICA 100-1 display, (z-19020) Controller output in display

#### Cascade operation




Fig. 3-22 Master controller TICA 100-2 (z-19021)





Fig. 3-23 Slave controller TICA 100-1 (z-19022)

#### Operating mode switching

Switching is always in the sequence below:



Manual operation applies only to the slave controller. Both in manual and automatic mode the master controller is always synchronised in such a manner that the switchover can take place smoothly.

When switching, the selected operating mode does not come into effect until 3 s have elapsed since the last key press.

At the same time as the operating mode is changed, the display also switches to the more important loop. It is always possible to switch manually to the other loop.

Manual → automatic on Loop 1  
Automatic → cascade on Loop 2  
Cascade → manual on Loop 1  
Cascade → automatic on Loop 1

**OUT always shows the actual output to the final control element or the final control element position reported back.**

By switching from automatic to cascade the slave controller switched to **external set point**, the master controller's output. The transition from automatic to cascade is performed smoothly as the master controller's output is synchronised in such manner that the slave controller is not subjected to any control deviation at the moment of switchover.

When changing from automatic to cascade the system automatically switches to loop 2, the master controller.

#### Control actions allowed

Display	Keys/Operating mode	Master controller	Slave controller
	<b>Manual MO</b>		
	<SP-w>	+	+
Sxt	<▲> <▼>	+	+
	<M/A/C>	operates on slave contr.	+
OUT	<▲> <▼>	-	+
	<b>Automatic AO</b>		
	<SP-w>	+	+
Sxt	<▲> <▼>	+	+
	<M/A/C>	operates on slave contr.	+
OUT	<▲> <▼>	-	-
	<b>Cascade CO</b>		
	<SP-w>	+	-
Sxt	<▲> <▼>	+	-
	<M/A/C>	operates on slave contr.	+
OUT	<▲> <▼>	-	-

+ operative, can be changed, - inoperative in this operating mode

### 3.10.2 Cascade with several slave controllers (not P100)

#### General

The integral controllers in a device in a cascade with several slave controllers have their own mode selector switches which are largely independent. Thus the operation of such controllers is similar to the operation of the equivalent cascade comprising individual controllers.

For the master controller there is the additional operating mode **TRACK** in which none of the three LEDs on the <M/A/C> key is lit. This operating mode is imposed through the slave controller's operating mode and cannot be changed at the master controller.

#### Cascade with two slave controllers with the same set point.




Fig. 3-24




Fig. 3-25  
(z-19027)




Fig. 3-26 (z-19023)

The master controller gives the same set point to both slave controllers. The controller output (OUT = 0...100%) produces the set point range configured in the slave controllers.

The controller output is not displayed on the master controller.

Operating modes available:

Open cascade with

- Manual operation in both slave controllers or
- one slave controller in manual and one in automatic mode or
- both slave controllers in automatic mode

Closed cascade with

- both slave controllers in automatic mode
- just one slave controller in automatic mode

#### Important

When the first slave controller is switched to cascade the controller is switched to manual. At first the output signal altered, but this can be done manually.

Where there is a large difference between set points following message is displayed before switching over (Fig. 3-25).

A set point jump can be avoided by:

- Resetting: first set both controllers to automatic mode and then adjust set points to equal.
- Defining a set point ramp

As long as one slave controller is still set to automatic, when the master controller is switched to automatic the following message is issued (Fig. 3-26).

After this message is acknowledged by pressing <Enter>, the intended switchover is performed. The master controller then operates on only one slave controller.

When slave controllers are reset from cascade to automatic the master controller retains its operating mode as long as one slave controller remains in cascade.

#### Operating modes

Loop 1: Slave controller 1	Loop 2: Slave controller 2	Loop 3: Master controller
Manual	Manual	Track
Automatic	Manual	Track following slave controller 1
Manual	Automatic	Track following slave controller 2
Automatic	Automatic	Track average
Cascade	Manual or Automatic	Manual or Automatic
Manual or Automatic	Cascade	Manual or Automatic
Cascade	Cascade	Manual or Automatic

Table 3-2 Track following slave controller: The slave controller's setpoint synchronises the master controller  
Track average: The master controller is synchronised to the average of the slave controller's setpoints.

### Cascade with two slave controllers and ratio station (not P100)




Fig. 3-27 Example:  
 Loop 3 temperature controller  
 Loop 2 air flow rate controller  
 Loop 1 gas flow rate controller




Fig. 3-28  
 (z-19027)




Fig. 3-29  
 (z-19023)

A ratio station is connected between the master controller and the slave controllers. Using an adjustable ratio, this distributes the master controller's output signal to the two slave controllers as set points.

Operating modes available:

Open cascade with

- Manual operation in both slave controllers or
- one slave controller in manual and one in automatic mode or
- both slave controllers in automatic mode

Closed cascade with

- both slave controllers in automatic mode
- just one slave controller in automatic mode

The ratio station is always in automatic mode, and the input signal apportioned to both outputs.

#### Important

When the first slave controller is switched to cascade the master controller is switched to manual. At first the output signal is not altered, but this can be done manually.

If the set point total is > 100%, before actually switching over the system issues the message: Fig. 3-28.

A set point jump can be avoided by:

- Resetting: first set both controllers to automatic mode and then adjust set points to equal.
- Defining a set point ramp

As long as one slave controller is still set to automatic, when the master controller is switched to automatic the following message is issued: Fig. 3-29.

After this message is acknowledged by pressing <Enter>, the intended switchover is performed. The master controller then operates on only one slave controller.

When slave controllers are reset from cascade to automatic the master controller retains its operating mode as long as one slave controller remains in cascade.

### Operating modes

Loop 1: Slave controller 1	Loop 2: Slave controller 2	Loop 3: Master controller
Manual	Manual	Track not alterable
Automatic: SP = SP1i	Manual	Track: SP1i/SR
Manual	Automatic: SP = SP2i	Track: SP2i/(1-SR)
Automatic: SP = SP1i	Automatic: SP = SP2i	Track: SP1i + SP2i < 100 %
Cascade	Manual or Automatic	Manual or Automatic
Manual or Automatic	Cascade	Manual or Automatic
Cascade	Cascade	Manual or Automatic

Table 3-3

SP1i = current set point on controller 1

SP2i = current set point on controller 2

Track SP1i/SR:

The master controller's output is synchronised to the value of SP1i/SR as long as this value is less than 100 %.

Track SP2i/(1-V):

The master controller's output is synchronised to the value of SP2i/(1-SR) as long as this value is less than 100 %.

Track SP1i + SP2i < 100%

The master controller's output is synchronised to the value of SP1i + SP2i as long as this value is less than 100 %.

### 3.10.3 Combustion control (not P100) (Load control)




Fig. 3-30 G = gas (fuel)  
A = air




Fig. 3-31  
(z-19025)

Load control ensures that as the load changes, a shortage of air is never allowed to occur.

Operating modes available:

Open cascade with

- Manual operation in both slave controllers or
- one slave controller in manual and one in automatic mode or
- both slave controllers in automatic mode

Closed cascade with

- both slave controllers in automatic mode

Some of the operation modes can be locked by changing the configuration.

The master controller cannot be switched to manual mode until the slave controllers are operating in cascade mode.

If this is not the case, the following message is issued if an attempt is made to switch the master controller from track to manual or automatic:  
Fig. 3-31.

This message cannot be suppressed.

When both slave controllers are switched commonly from cascade to automatic the master controller is switched to manual. At first the output signal is not altered, but this can be done manually.

When a slave controller is switched back to manual the master controller is automatically switched to track operation.

#### Operating modes

Loop 1: Slave controller 1	Loop 2: Slave controller 2	Loop 3: Master controller
Manual	Manual	Track
Automatic: Fixed value A, SP= SP1i	Manual	Track: SP1i/SR
Manual	Automatic: Fixed value G, SP= SP2i	Track: SP2i
Automatic: Fixed value A, SP= SP1i	Automatic: Fixed value G, SP= SP2i	Track: A/R
Cascade	Automatic	Manual
Automatic	Cascade	Manual
Cascade	Cascade	Manual or Automatic

Table 3-4 Track:  
Controller is locked in Track mode.  
Track A/R:  
The controller output is synchronised to the air/ratio value  
A = Air  
G = Gas (fuel)  
R = Ratio

### 3.11 Override-control

(Limiting control)




Fig. 3-32 3 override controllers  
(z-19098)




Fig. 3-33 1 Override controller  
Override control of pressure P  
Primary controlled variable: flow F

In override control one primary controlled variable is managed. One or more additional controllers make sure that the (limiting) set points are neither over- nor under-stepped. All the controllers here access a single final control element.

Example (Fig. 3-32):

Primary controlled variable: Flow

Limitation of: Pressure  
Temperature  
Current drain by the compressor drive

Operating modes available:

The mode selector switches only ever affects loop 1. Every time there is a mode change the system switches automatically to loop 1.

The operation of the limiting controllers is restricted to setting set points.

Manual operation (M)

The main controller is in manual mode, the limiting controller(s) is/are in automatic mode.

The limiting controllers can't be switched to manual.

Manual operation is carried out only through loop 1. The limiting controllers are not involved.

Automatic (A)

The main controller is in automatic and is the only unit working on the final control element.

The limiting controllers are not involved.

Cascade (C)

The main controller and limiting controllers are engaged.

If a limiting controller should become temporarily inoperative its set point must be altered to the limit of the range and thus rendered inoperative.



### 3.12 DDC-Control (Direct Digital Control)

With DDC control a supervisory computer provides for control. In case of a computer failure the Digitric controller bumplessly takes over control via interface RS 485 (MODBUS RTU) or PROFIBUS DP. The superimposed computer writes via the bus on the variables Lx\_YCOMPUTER of the respective loop X and, thus, determines the controller output. In case the superimposed computer should fail, the controller itself bumplessly takes

#### Possible operating modes

- LED is off
- ⊙ LED is flashing with 0,5 to 1 Hz
- ⊗ LED is flashing with 2 Hz
- ✱ LED is on
- CR The computer is ready, i.e. there is regular data traffic via the serial interface.
- M, A, C LEDs to the side of button 19 on the front panel (Fig. 3-1)

#### DDC configuration with manual backup mode

Operating mode	LED			CR
	M	A	C	
Manual	✱	●	●	0
Automatic	●	✱	●	0
DDC	disabled			0
Manual	✱	●	⊙	1
Automatic	●	✱	⊙	1
DDC	✱	●	✱	1
Backup mode				
M-backup	✱	●	⊗	0
M-backup	✱	●	✱	1

#### DDC configuration with automatic backup mode

Operating mode	LED			CR
	M	A	C	
Manual	✱	●	●	0
Automatic	●	✱	●	0
DDC	disabled			0
Manual	✱	●	⊙	1
Automatic	●	✱	⊙	1
DDC	●	✱	✱	1
Backup mode				
M-backup	●	✱	⊗	0
M-backup	●	✱	⊙	1

#### DDC configuration with cascade backup mode

Operating mode	LED			CR
	M	A	C	
Manual	✱	●	●	0
Automatic	●	✱	●	0
Cascade	●	●	✱	0
DDC	disabled			0
Manual	✱	●	⊙	1
Automatic	●	✱	⊙	1
Cascade	●	⊙	✱	1
DDC	●	✱	✱	1
Backup mode				
M-backup	●	⊗	✱	0
M-backup	●	⊙	✱	1

#### No computer ready signal (CR = 0)

As long as no computer ready (CR) signal is available, the controller cannot be switched to DDC mode.

#### Computer ready (CR = 1)

The changeover to DDC operation is enabled. In "manual" mode LED A flashes with low frequency. In "automatic" backup mode LED M flashes with low frequency.

It is possible to switch from DDC operation to manual or automatic mode at any time.

#### Computer not ready

If the CR signal is not received any longer, the controller takes over control in the configured mode.

In backup mode "manual" LED A flashes with increased frequency.

In backup mode "automatic" LED M flashes with increased frequency.

It is not possible to switch over to another mode (non-DDC).

The LED of the disabled mode flashes. The LED of the active mode is lighted permanently.

### 3.13 Stations

#### 3.13.1 Manual station




Fig. 3-34

Operating mode	LED				CR
	M	A	C		
Manual	✱	●	●		0
DDC	disabled				0
Manual	✱	●	○		1
DDC	✱	●	✱		1
Backup mode					
M-backup	✱	●	⊗		0
M-backup	✱	●	○		1

The manual station is a controller that can be used in "manual" mode only. All indicators that can be selected by pressing <Ind> do not display setpoints or the control deviation in this mode. The PV indicator can indicate a measured value which can be monitored for limit values. The operation of the manual station depends on the respective configuration.

##### Manual station

With the manual station the control output can be set manually. All output types of the controller are possible.

##### Manual/automatic station (not step controller)

In automatic mode, this station applies an externally fed continuous signal to the output. It is possible to switch over to manual mode and set the output manually. No step output is possible.

##### DDC manual station (not step controller)

The DDC manual station combines the functionality of the manual station with the manual function of the DDC controller.

#### 3.13.2 Setpoint station





Fig. 3-35

The setpoint station generates setpoints and outputs them as 0/4...20 mA signal.

All indicators for the process value or control deviation are disabled.

The button <Sp-w> can be used to switch between different setpoint sources and the program generator, if configured.

### 3.13.3 Ratio station




### 3.13.4 Positioner

The positioner is a motorized valve controller (step controller) which tracks the actuator position (valve position) to an external setpoint. This task requires position feedback.

The returned position is indicated on the controller as the process value PV and the position feedback OUT.

## 3.14 Remote control (Profibus or Modbus)



## 4 Error information on the display

Operating notes	Meaning	Configuration
locked by BI	Access to parameterization, configuration, service, and supervisor level is blocked through a binary input.	I-B02-Q01 I-B02-Q02
generate	After configuration the instrument is busy with the program generation.	
locked for ST	Self-tuning is blocked for this control loop. It can only be released via the configuration.	L1- B01-Q05
no adjustment possible	The selected input has not been activated for the type intended for the adjustment (e. g. no Pt100 input). This message is displayed for mA position feedback or remote transmitters fed with constant current, if the difference between start and end value is smaller than 10%.	
no adjustment	The configured module does not permit an adjustment respectively does not require an adjustment.	
local only	The instrument has only been configured for local operation. It cannot be switched to exclusive remote operation.	I-B04-Q01
remote only	The instrument has been configured for remote operation. For local operation it must be enabled via menu "Operate 2" or via the configuration.	I-B04-Q01

Table 4-1 Error information

Error message	Cause	Remedy
Error xxxx	An error occurred while processing the program. The number is intended as help for the service.	If this message does not disappear within a few seconds you can try to initiate a restart by switching off the supply voltage for approximately 60 s. If the error persists, the factory settings must be restored via the "supervisor" menu or the configuration must be reloaded via IBIS_R .
IP stopped!	Processing has been temporarily stopped. This error occurs during downloading.	If this message does not disappear within a few seconds after downloading you can try to initiate a restart by switching off the supply voltage for approximately 60 s. If the error persists, the factory settings must be restored via the "supervisor" menu or the configuration must be reloaded via IBIS-R .
Slot X!	When downloading a configuration the configuration request a module that is located in the instrument.	Insert the correct module in slot X and register the module (I-B11-Q01 = 1). Note: X = 1 to 4
invalid response	The response entered may be incompatible with other existing settings. Enter is activated together with this message.	Get the invalid response on the display with <Enter> and change it.
Card fault	There was an attempt to read or write the configuration on a defective memory card.	Try again. If fault persists, use another memory card.
No M-card	There was an attempt to read or write the configuration of a memory card which is not available.	Push memory card into the terminal provided on device.
Confi. incomplete	The configuration stored on the memory card is incomplete.	
write protection	There was an attempt to write the configuration on a write-protected memory card.	

Table 4-2 Error information

## 5 Menu structure




Fig. 5-1 Menu structure  
 1 Confirm selection, go down one menu level  
 2 Change or confirm input, go down one menu level  
 3 Go up one menu level without change (press 3 s → main operating level)  
 4 From main operating level to menu  
 5 Move sideways within one menu level

### Indication 2

In this menu you can view all parameters, measuring values, and settings of the controller, but you cannot change them (see also chapter 5.1 "Indication 2" on page 26).

### Operate 2

In this menu you can toggle between local and remote operation.  
 (See also chapter 5.2 "Operate 2" on page 28.)

### Selftune

Self-tuning is enabled in the configuration menu under  
 CONF1 / LOOP1 / B01 / Q05  
 After enabling it can be used without knowing a password.  
 (See Configuration Instruction 42/62-50012.)

### Parameter

This menu contains the settings of the parameters required for the configured functionality. During parameterization the control action stays on. (See Configuration Instruction 42/62-50012.)

### Configuration

This menu contains sub-menus for instrument function definition (e. g. actuator output type).  
 During configuration the control action is switched off (actuator outputs are frozen).  
 (See Configuration Instruction 42/62-50012.)

### Service

This menu contains sub-menus for calibration, Adjustment, etc. (see also "Configuration Instruction" 42/62-50012).  
 Calibration is only required in exceptional cases. If it is not executed in an expert manner, the instrument is rendered unusable.

### Supervisor

This menu contains the sub-menus: Master reset, Plausibility, and Template. (See "Configuration Instruction" 42/62-50012.)

## 5.1 Indication 2

Example navigation in menu „Indication 2“




Fig. 5-2 Navigation in menu „Indication 2“

### 5.1.1 Inputs/outputs

Fig. 5-3  
z-19081

Fig. 5-4  
z-19082

Fig. 5-5  
z-19083

In this menu you can display all binary and analog inputs and outputs used in the application.

Press <Enter> to switch to the next menu level.


The value of analog input AI01 is displayed in the first line of the selected scale.

The bottom line shows the PV. In simple control tasks with only one measuring value both values are identical, possibly with different decimal point position.


Press <▲> and <▼> to select the desired input or output.

Currently, binary input BI01 has the value logical "1".


### 5.1.2 Parameter display

 <p>Fig. 5-6 Parameter display z-19104</p>	<p>In this menu you can display all parameters of the instrument.</p> <p>Parameter changes can only be performed via the password-protected parameterization menu.</p>
---	--


### 5.1.3 Effective PID parameter

 <p>Fig. 5-7 PID parameter display z-19104</p>	<p>In this menu you can display the effective PID parameters of the instrument.</p> <p>Parameter changes can only be performed via the password-protected parameterization menu.</p>
---	--

### 5.1.4 Identification

 <p>Fig. 5-8 The display shows an example of the information when called from Loop 1. z-19065</p>	<p>Selecting menu option "Identification" displays the function of the selected control loop.</p>
--	---

### 5.1.5 Library identification

 <p>Fig. 5-9 Library identification z-19080</p>	<p>The configuration is based on library 3.6.0. This information is only relevant for processing the configuration with IBIS-R.</p>
--	---

### 5.1.6 Version display

```

FW Vers: 01.250
PV
°C 300.0
SP1
°C 310.0
|
  
```

Fig. 5-10 The firmware (instrument software) has the z-19042 Index 01.250

This is the firmware version used in the instrument itself. It may be required to know this version number when using the IBIS-R PC software.

### 5.2 Operate 2

```

only local !
PV
°C -25.0
SP1
°C -26.5
|
  
```

Fig. 5-11 Not intended for remote operation z-19041

```

Rem > Local ?
PV
°C 25.0
SP1
°C 26.5
|
  
```

Fig. 5-12 Remote operation is activated z-19040

```

Local > Rem ?
PV
°C 25.0
SP1
°C 26.5
|
  
```

Fig. 5-13 Remote operation is deactivated z-19039

If the instrument has been configured exclusively for remote operation, the remote operation can be disabled temporarily – e. g. for emergency intervention – via menu "Operate 2".

Depending on the configuration the following display appears when selecting the menu option:

#### Not intended for remote operation

The operation cannot be changed.

#### Note

Remote operation means that values are input to the instrument via Modbus RTU respectively PROFIBUS DP.

#### Remote operation is activated

Remote operation "Rem" can be toggled to local operation.

The question "Toggle to local operation?" = "Rem>Local?" is confirmed with <Enter> or negated with <Esc>.

If the instrument is toggled to local operation the keys are enabled and [Rem] starts flashing.

#### Remote operation is deactivated

Remote operation is – temporarily – switched off. Press <Enter> to restore the operating condition "Remote operation" as defined by the configuration. Then, the instrument can only be remote-operated.

[Rem] stops flashing.



### 6 Password protection




Fig. 6-1 Input of password. 1st field from the right  
z-19101




Fig. 6-2 Locking the parameterization and configuration level via binary input  
z-19103

If the password protection has been configured (I-B20), you must enter a password to access the protected levels, by changing the predefined value "00000".

The password is a 5-digit number.

1. Shift a flashing (= changeable) field:  
<Ind>
2. Change digit:  
<▲> and <▼>
3. Confirm password:  
<Enter>

When the password is correct, the desired level is entered. You can now switch between all levels of the menu system without having to re-enter the password  
(Question: I-B20-Q01).

If the password is not correct, the main operating level is displayed again.

If a hardware lock has been configured (I-B02-Q01) and the binary input is set, the message "locked by BI" is displayed when attempting to open a protected level.

The message is displayed for 3 s, then the operating level is automatically switched back.

#### Cancelling the password input

Cancel with <Esc>

#### Forgotten password

If a password is no longer known, the password can be reset by temporarily rearranging a jumper within the instrument. For this action the control loop must be switched off.

## 7 Index

	Seite
<b>A</b>	
Alarm handling .....	11
Automatic mode .....	11
<b>C</b>	
Cascade control .....	16
Cascade with one slave controller .....	16
Cascade with several slave controllers .....	17
Cascade with two slave controllers and ratio station .....	18
Channel switching .....	11
Combustion control .....	19
<b>D</b>	
DDC-Control .....	21
Direct Digital Control .....	21
Display color switchover .....	10
<b>E</b>	
Effective PID parameter .....	27
Error information on the display .....	24
<b>F</b>	
Forgotten password .....	29
<b>I</b>	
Identification .....	27
Indication 2 .....	25, 26
Inputs/outputs .....	26
<b>L</b>	
LC-Display .....	10
Library identification .....	27
Limiting control .....	20
Load control .....	19
<b>M</b>	
Manual mode .....	12
Manual station .....	22
Menu structure .....	25
<b>N</b>	
navigation in menu „Indication 2“ .....	26
<b>O</b>	
Operate 2 .....	25, 28
Operating elements .....	9
Operating modes .....	18
Operation .....	9
Override-control .....	20
<b>P</b>	
Parameter display .....	27
Password protection .....	29
Positioner .....	23
Programmer .....	14
<b>R</b>	
Ratio controller .....	13
Ratio station .....	23
Remote control .....	23
<b>S</b>	
Selftune .....	25
Service .....	25
Setpoint station .....	22
Stations .....	22
Supervisor .....	25
Symbols .....	6
<b>V</b>	
Version display .....	28



The Industrial<sup>IT</sup> wordmark and all mentioned product names in the form XXXXX<sup>IT</sup> are registered or pending trademarks of ABB.

ABB has Sales & Customer Support expertise in over 100 countries worldwide.

[www.abb.com](http://www.abb.com)

# ABB

## ABB Automation Products GmbH


Hoeseler Platz 2  
42579 Heiligenhaus  
Germany

Tel: +49 2056 12-5181  
Fax: +49 2056 12-5081

The Company's policy is one of continuous product improvement and the right is reserved to modify the information contained herein without notice.

Printed in the Fed. Rep. of Germany (07.03)

© ABB 2003





## Notes

All safety notes and displays in these operating instructions apply to both the Protronic 500 and the Protronic 550

## Contents

<b>PROCESS OPERATION .....</b>	<b>3</b>
Description of the operator panel.....	3
Display switch-over .....	5
Alarm handling .....	6
Alarm message .....	6
Alarm acknowledgement .....	6
<b>PAST-HISTORY MODE.....</b>	<b>7</b>
Quitting past-history mode.....	7
Updating the recording .....	8
<b>OPERATOR CONTROL LEVEL 2 .....</b>	<b>9</b>
Indicating 2 .....	9

## Process operation

### Description of the operator panel




Fig. 1 Protronic 550 - trend display

- |    |   |        |  |
|----|---|--------|--|
| 1  | Measurement point number (TAG 12-digit)   | 15     | "Raise" adjustment of the value displayed in 5,6,7   |
| 1a | Message line  | 16     | Display selector switch for 5,6,7  |
| 2  | Digital display controlled variable X   |        | LED lights up in past-history mode   |
| 3  | Label controlled variable X   | 17     | "Lower" adjustment of the value displayed in 5,6,7   |
| 4  | Dimension controlled variable X   | 18     | Channel (loop) switch-over, shift key for key 16   |
| 5  | Digital display which can be changed over with <Ind>: in automatic mode normal W, in manual mode normal Y | 19     | Operating mode transfer, manual-automatic (cascade) with associated LEDs   |
| 6  | Label of the value displayed  | 20     | Entry into the parameter-definition and configuration levels. Associated LED lights up immediately the operator control level has been left. |
| 7  | Dimension of the value displayed  | 21     | Acknowledgement of alarms and parameter setting and configuration data   |
| 8  | Number of the control loop displayed changes with "A" in alarm  | 22     | Manual mode "raise"  |
| 9  | Display for active programmer   | 23     | Manual mode "lower"  |
| 10 | Display for activated remote control  | 24/24a | Controller output Y  |
| 11 | Binary flags (freely configurable messages for binary events)   | 25     | Closing screw  |
| 12 | Analog display controlled variable X  |        |  |
| 13 | Analog display setpoint W   |        |  |
| 14 | Setpoint switch-over  |        |  |

The numbers of the individual control and display elements are used identically in all parts of the documentation of the unit.




Fig. 2. Trend display




Fig. 3. Numerical display



selected loop


Process Variable PV (1)

Setpoint SP1 (2)

Output OUT (3)  
of selected loop

Process Variable PV  
of selected loop

Output OUT of  
selected loop



actual operation modes

Message line

Ind.-line of selected loop




Fig. 5 Overview display with one to four loops

## Display switch-over

Holding down <Loop> switches over the displays cyclically at intervals of 2 seconds.

## Alarm handling

### Alarm message




Fig. 6. Trend display with alarm window

If an alarm message has been configured in the display,

- a flashing error message with precise information on the cause of the fault and the value of the infringed alarm value is entered in the display field
- the red LED next to the <Enter> key lights up,

when an alarm value infringement or an error in the operating cycle occurs.

### Alarm acknowledgement

Alarms displayed are acknowledged with <Enter>.

If further alarms are present, they are acknowledged either singly or collectively, depending on the configuration.

Acknowledged alarms are no longer visible.

## Past-history mode




Fig. 7 Past-history mode

"The transfer to "past-history" mode is achieved by holding down the <Loop> key and actuating the <Ind> key. The LED in the <Ind> key lights up.

300 values (each) which were stored up to the moment of mode transfer, are displayed for X, W and Y. After this they are then no longer updated automatically and remain until an updating, or a new calling of the past-history mode (see "Quitting").

The interval between the measured values is defined by the configuration of the trend display.

The controller cannot be operated in this mode. It is not possible to change setpoint, correction value or operating mode.

The recording of the current values continues without interruption in the configured loops (1 to 4).

It is possible each time to scroll 75 points of the recording using the <>> and <<> keys.

### Quitting past-history mode

There are two ways of quitting the past-history mode:

#### 1. Temporary quitting

Quitting without deleting the display

- during an update or
- in order to look at the stored values again later.

Key <Ind>

#### 2. Final quitting

If the past-history mode is called again, the current values of the current loop are automatically brought into the display.

Key <Esc> followed by key <Ind>

## Updating the recording




Fig. 8. Updating

After the past-history mode has been called, the values stored for the display can be updated at any time. This possibility is signalled in the message line.

Ready f. record

Three options are offered for this.

1. 300 measured values stored in the direct past history
2. 75 measured values in the direct past history and the recording of a further 225 updated measured values
3. The recording of 300 new measured values.

The keys <Sp-w>, <<> and <>> are used to call one of these updates. These keys now have the following functions:

<Sp-w> = <New> copies 300 values from the direct past into the display memory. The transfer of the measured values into the memory is confirmed in the message line.

new rec. ready

<A> = <A4/4> starts the recording of 300 new values. The fact that recording is taking place is confirmed in the message line:

rec 4/4 runs

<V> = <A3/4> copies the 75 newest values into the display memory and starts the recording of 225 new values. The fact that recording is taking place is confirmed in the message line.

rec 3/4 runs

Immediately the measured values are available the message appears in the message line

rec 3/4 ready

or

rec 4/4 ready

The data are always stored in the display memory and they remain available in this until they are overwritten by new data.

It is possible each time to scroll 75 points of measurement with the <<> and <>> keys.

<Esc> = <Stop> aborts the updating.

## Operator control level 2

### Indicating 2




Fig. 9 Operator control level 2, displays 2

Subject to technical changes.

This technical documentation is protected by copyright. Translating, photocopying and disseminating it in any form whatsoever - even editings or excerpts thereof - especially as reprint, photomechanical or electronic reproduction or storage on data processing systems or networks is not allowed without the permission of the copyright owner and non-compliance will lead to both civil and criminal prosecution.

# ABB

---

**ABB Automation Products GmbH**  
Hoeseler Platz 2  
D-42579 Heiligenhaus  
Phone +49 (0)20 56 12 - 51 81  
Fax +49 (0)20 56 12 - 50 81  
<http://www.abb.com>

Subject to technical changes.  
Printed in the Fed. Rep. of Germany  
42/62-55013 EN Rev. 01  
Edition 11.01